



SAMSUNG
Electronics



HQ



PAL

SERVICE MANUAL

MODEL: VX-1560

SVM-P10-002-1 E
68139 - 102 - 102

VIDEO CASSETTE RECORDER



SPECIFICATION

Format :	VHS PAL standard
Recording System :	Double Azimuth 4 Rotary Heads Luminance : FM azimuth recording Colour : Down converted subcarrier phase shifted direct recording
Television System :	PAL colour and B/W signal
Tape Width :	12.65 mm (1/2 inch)
Tape Speed :	SP : 23.39 mm/sec LP : 11.67 mm/sec
Record/Playback Time :	SP : 4 hours with E-240 type LP : 8 hours with E-240 type
FF/REW Time :	Less than 6 min. with F-120
Heads :	Video : Double Azimuth 4 Rotary Heads Audio/Control : 1 stationary head Erase : 1 full track erase
VIDEO	
Input :	0.5 to 2.0 Vp-p ; 75 ohm unbalanced
Output :	1.0 Vp-p ; 75 ohm unbalanced
Signal-to-Noise Ratio :	Better than 43 dB (SP) Better than 40 dB (LP)
Horizontal Resolution:	More than 240 Lines (SP) More than 220 Lines (LP)

AUDIO	
Input :	Line : -8 dBm, 50K ohm unbalanced
Output :	Line : -4 dBm, 1K ohm unbalanced
Wow-Flutter :	0.4% Max (SP) 0.8% Max (LP)
Frequency Response :	100 Hz - 8 KHz (SP) 100 Hz - 5 KHz (LP)
Receiving Channel :	VX : VHF LOW, VHF HIGH, UHF VI : UHF (Band IV/V) : CH 21 - 69
Power Requirement :	220/240V AC, 50Hz
Power Consumption :	Approx. 26 watts
Operating Temperature :	41 ° F - 104 ° F (5 ° C - 40 ° C)
Operating Humidity :	10% - 75%
Weight :	6.2 kg
Dimensions :	420 (W) x 86 (H) x 315 (D)mm

CONTENTS

1. GENERAL DESCRIPTION

1-1. Safety Precautions.....	1-1
1-2. General Information	1-3
1-3. Operating Controls and Functions	1-4
1-4. Cleaning and Lubrication	1-11
1-5. Abbreviations	1-12

2. DISASSEMBLY

2-1. Instrument Disassembly	2-1
2-1-1. Top Cabinet Removal	2-1
2-1-2. Bottom Cover Removal	2-1
2-1-3. Front Panel Removal	2-1
2-1-4. Main Circuit Board Removal	2-1
2-1-5. Function Switch Circuit Board Removal	2-1
2-1-6. Timer Input Key Circuit Board Removal	2-2
2-1-7. Pre-Amp Circuit Board Removal	2-2
2-1-8. Regulator Circuit Board Removal	2-2
2-2. Mechanical Disassembly	2-3
2-2-1. Housing Assembly Removal	2-5
2-2-2. PWB Sensor (S) Assembly Removal	2-5
2-2-3. PWB Sensor (E) Assembly Removal	2-6
2-2-4. Sub Assembly Removal	2-6
2-2-5. Side Arm Assembly	2-6
2-2-6. Arm Gear Removal	2-6
2-2-7. Cassette Holder Assembly Removal	2-7
2-2-8. Side Chassis (L) Assembly Removal	2-7
2-2-9. Joint Gear, Arm Gear and Eject Slide Assembly	2-7
2-2-10. Deck Assembly and Assembly of F/L Housing Assembly	2-7
2-2-11. Cylinder Assembly Removal	2-8
2-2-12. Upper Cylinder Removal	2-9
2-2-13. Lower Cylinder Removal	2-9
2-2-14. Cylinder Motor Removal	2-10
2-2-15. Cylinder Assembly Removal from Main Base	2-10
2-2-16. Loading Assembly and E/J Drive Bracket Removal	2-10
2-2-17. Brake Lever Cam Assembly Removal	2-11
2-2-18. Worm Gear Wheel, Master Cam and Eject Drive Gear Removal	2-11
2-2-19. Pinch Roller Lever Assembly Removal	2-11
2-2-20. Sector Gear Removal	2-11
2-2-21. Loading Gear L/R Removal	2-12
2-2-22. Reel Disk "R" Removal	2-12
2-2-23. Reel Disk "L" Tension Band & Tension Arm Removal	2-12
2-2-24. Sub Brake L/R and REC Lever Switch Removal	2-12
2-2-25. Main Brake L/R and Tension Lever Control Removal	2-13
2-2-26. Capstan Motor and Capstan Motor Brake Removal	2-13
2-2-27. Idler Clutch and Shift Lever Removal	2-13
2-2-28. Main Brake Slide Removal	2-13
2-2-29. PWB Reel Removal	2-14
2-2-30. Idler Sub Assembly Removal	2-14
2-2-31. Assembly LED Removal	2-14
2-2-32. Worm Gear Position (Eject Mode)	2-14

2-2-33. Pinch Roller Assembly and Master Cam Gear Assembly	2-14
2-2-34. Brake Cam Lever, Eject Drive Gear and Master Cam Gear Assembly	2-15
2-2-35. ASS'Y Loading Unit and Master Cam Gear Assembly	2-15
2-2-36. Sector Gear and Loading Gear Assembly	2-16
2-2-37. Pole Base Removal	2-16
2-2-38. Audio Control Head Assembly Removal	2-16
2-2-39. Review Arm Assembly Removal	2-17
2-2-40. Full Erase Head Removal	2-17

3. MECHANICAL ADJUSTMENT

3-1. Mechanical Adjustment Tools	3-1
3-2. Tape Transport System Adjust Flow Chart	3-2
3-3. Tape Transport System	3-3
3-3-1. Location of Tape Transport Adjustment	3-3
3-3-2. Tape Transport System Adjustment	3-4
3-4. Reel Torque	3-6
3-4-1. General Features	3-6
3-4-2. Location of Tension Pole and Back Tension Adjustment	3-7
3-4-3. Reel Torque Adjustment	3-7

4. ELECTRICAL ADJUSTMENT

4-1. Preparation	4-1
4-1-1. Required Test Equipment	4-1
4-1-2. Alignment Tape Contents	4-2
4-2. Servo Section in Main. PCB	4-3
4-2-1. Switch Point Adjustment	4-3
4-3. LUMA/CHROMA Section in Main. PCB	4-3
4-3-1. CCD IN (CLAMP) Level Adjustment	4-3
4-3-2. FM Carrier & Deviation Adjustment	4-4
4-4. Tuner/Demodulator Section in Main. PCB	4-4
4-4-1. Trap Adjustment	4-4
4-4-2. VIF Adjustment	4-5
4-4-3. AFT Adjustment	4-5
4-4-4. RF AGC Adjustment	4-6
4-5. Audio Section in Main. PCB	4-6
4-5-1. Audio Bias Level Adjustment	4-6
4-6. LP SKEW Section	4-7
4-6-1. LP SKEW Adjustment	4-7

5. TIMING CHART/TROUBLESHOOTING GUIDES

5-1. Timing Chart	5-1
5-1-1. Play/Unload/Play	5-1
5-1-2. Eject/Unload/Eject	5-1
5-1-3. Stop/Rew	5-2
5-1-4. Play/Stop/Play	5-2
5-1-5. Play/FPS/Play	5-3
5-1-6. Play/RPS/Play	5-3
5-1-7. Play/Still	5-4

5-1-8. Stop/REC/Stop	5-4
5-1-9. Pause/REC/Pause	5-5
5-2. Troubleshooting Guide	5-6
5-2-1. Index Mark Inoperative	5-6
5-2-2. Index Search Inoperative	5-6
5-2-3. Index Erase Inoperative	5-7
5-2-4. No Power	5-7
5-2-5. Drum does not Rotate	5-8
5-2-6. Capstan does not Rotate	5-8
5-2-7. FWD Search Mode Inoperative	5-9
5-2-8. REV Search Mode Inoperative	5-9
5-2-9. Noise Picture in Play	5-10
5-2-10. Tuning Inoperative	5-10
5-2-11. RF Video Missing in EE Mode	5-11
5-2-12. Video Missing in EE Mode	5-11
5-2-13. Video Missing in Play Mode	5-12
5-2-14. Video Missing in Record Mode	5-12
5-2-15. Colour Missing in Play Mode	5-13
5-2-16. Colour Missing in Record Mode	5-13
5-2-17. RF Audio Missing in EE Mode	5-14
5-2-18. Audio Missing in EE Mode	5-14
5-2-19. Audio Missing in Play Mode	5-15
5-2-20. Audio Missing in Record Mode	5-15

6. MECHANICAL/ELECTRICAL REPLACEMENT PARTS LIST

6-1. Mechanical Parts List	6-2
6-2. Electrical Replacement Parts List	6-3

7. MECHANICAL EXPLODED VIEWS

7-1. Instrument Assembly	7-2
7-2. Transport Mechanism Assembly	7-3
7-3. Bottom Side Mechanism Assembly	7-4
7-4. Housing Assembly	7-5

8. BLOCK DIAGRAMS

8-1. Total Wiring Diagram	8-2
8-2. Drum Phase Control	8-3
8-3. Drum Speed Control	8-3
8-4. Capstan Phase Control	8-4
8-5. Capstan Speed Control	8-4
8-6. Audio Playback Process	8-5
8-7. Audio Record Process	8-5
8-8. Luminance Playback Process	8-6
8-9. Luminance Record Process	8-7
8-10. Chrominance Playback Process	8-8
8-11. Chrominance Record Process	8-9

9. CIRCUIT BOARDS

9-1. Regulator (Top Side)	9-3
Regulator (Bottom Side)	9-4
9-2. Deck Joint (Top Side)	9-5
Deck Joint (Bottom Side)	9-6
9-3. Reel Sensor (Top Side)	9-5
Reel Sensor (Bottom Side)	9-6

9-4. Loading Motor (Top Side)	9-7
Loading Motor (Bottom Side)	9-8
9-5. Cassette LED (Top Side)	9-7
Cassette LED (Bottom Side)	9-8
9-6. Start/End Sensor (Top Side)	9-9
Start/End Sensor (Bottom Side)	9-10
9-7. A/C Head (Top Side)	9-9
A/C Head (Bottom Side)	9-10
9-8. Remote Control (VX/VI-1560) (Top Side)	9-11
Remote Control (VX/VI-1560) (Bottom Side)	9-12
9-9. Remote Control (VX-1561) (Top Side)	9-12
Remote Control (VX-1561) (Bottom Side)	9-12
9-10. Sync DET (OPTION) (Top Side)	9-11
Sync DET (OPTION) (Bottom Side)	9-12
9-11. Pre-Amp (Top Side)	9-13
Pre-Amp (Bottom Side)	9-14
9-12. VPS (OPTION) (Top Side)	9-13
VPS (OPTION) (Bottom Side)	9-14
9-13. OSD (OPTION) (Top Side)	9-15
OSD (OPTION) (Bottom Side)	9-16
9-14. CAP. FG AMP (Top Side)	9-15
CAP. FG AMP (Bottom Side)	9-16
9-15. LP SKEW (Top Side)	9-17
LP SKEW (Bottom Side)	9-18
9-16. Main (Top Side)	9-19
Main (Bottom Side)	9-20
9-17. Timer (VX/VI-1560) (Top Side)	9-21
Timer (VX/VI-1560) (Bottom Side)	9-22
9-18. Timer (VX-1561) (Top Side)	9-23
Timer (VX-1561) (Bottom Side)	9-24
9-19. Function (VX/VI-1560) (Top Side)	9-25
Function (VX/VI-1560) (Bottom Side)	9-26
9-20. Function (VX-1561) (Top Side)	9-27
Function (VX-1561) (Bottom Side)	9-28
9-21. Speed SUB (OPTION) (Top Side)	9-29
Speed SUB (OPTION) (Bottom Side)	9-30

10. SCHEMATICS DIAGRAMS

10-1. Regulator	10-2
10-2. Timer (VX/VI-1560)	10-3
10-3. Timer (VX-1561)	10-3
10-4. Servo/Power/System Control	10-4
10-5. Luminance/Chrominance	10-6
10-6. Audio	10-8
10-7. Tuner (VI Model)	10-8
10-8. Tuner/VPS (VX Model)	10-9
10-9. Pre-Amp	10-10
10-10. LP SKEW	10-11
10-11. OSD (OPTION)	10-12
10-12. Deck Joint	10-13
10-13. Function (VX/VI-1560)	10-14
10-14. Function (VX-1561)	10-14
10-15. Speed SUB (OPTION)	10-15
10-16. Remote Control	10-16

11. SEMICONDUCTOR LEAD IDENTIFICATION

11-1

1. GENERAL DESCRIPTION


1-1. SAFETY PRECAUTIONS

1. Before returning a Video Cassette Recorder to the customer, always make a safety check of the entire instrument, including, but not limited to the following items:

- Be sure that no built-in protective devices are defective and/or have been defeated during servicing.
 - Protective shields are provided on this chassis to protect both the technician and the customer. Correctly replace all missing protective shields, including any removed for servicing convenience.
 - When reassembling the instrument, be sure to put back in place all protective devices, including, but not limited to nonmetallic control knobs, insulating fish papers, adjustment and compartment covers/shields, and isolation resistor/capacitor networks.
- Do not operate this instrument or permit it to be operated without all protective devices correctly installed and functioning.

b. Be sure that there are no cabinet openings through which an adult or child might be able to insert their fingers and contact a hazardous voltage. Such openings include, but are not limited to, (1) excessively wide cabinet ventilation slots, and (2) improperly fitted and/or incorrectly secured cabinet covers.

c. Antenna Cold Check- With the instrument AC plug removed from any AC source, connect an electrical jumper across the line and neutral wires of all input. Place the instrument AC switch in the off position. Connect one lead of an ohmmeter to the AC plug prongs and touch the other ohmmeter lead in turn to each tuner antenna input exposed terminal screw and, to each of the coaxial connectors. If the measured resistance is less than 1.0 megaohm or greater than 5.2 megaohm, an abnormality exists that must be corrected before the instrument is returned to the customer.



C Leakage Test

Repeat this test with the instrument AC switch in the off position.

d. Leakage Current Hot Check- With the instrument completely reassembled plug the AC line cord directly into a 220 (240V-UK) AC outlet. (Do not use an isolation transformer during this test.) Use a leakage current tester or a metering system that complies with American National Standards Institute (ANSI) C101.1 Leakage Current for Appliances and Underwriters Laboratories (UL) 1410, (50.7). With the instrument AC switch first in the on position and then in the off position, measure from a known earth ground (metal waterpipe, conduit, etc.) to all exposed metal parts of the instrument (antennas, handle bracket, metal cabinet, screwheads, metallic overlays, controls shafts, etc.), especially any exposed metal parts that offer an electrical return path to the chassis. Any current measured must not exceed 0.5milliamp. Reverse the instrument power cord plug in the outlet and repeat test. Reverse the instrument's AC input live and neutral leads to the AC outlet and repeat the test.

ANY MEASUREMENTS NOT WITHIN THE LIMITS SPECIFIED HEREIN INDICATE A POTENTIAL SHOCK HAZARD THAT MUST BE ELIMINATED BEFORE RETURNING THE INSTRUMENT TO THE CUSTOMER OR CONNECTING ANTENNA OR ACCESSORIES.

e. AC Leakage Test
Avoid shock hazards. The television instrument, accessory, or cables (s) to which this VCR is connected should have the applicable sections of the leakage resistance antenna cold check and the leakage current hot check performed. Do not connect this VCR to a TV antenna, cable or accessory that exhibits excessive leakage currents.

2. Read and comply with all caution and safety related notices on or inside the VCR cabinet and chassis.

3. Design Alteration Warning- Do not alter or add to the mechanical or electrical design of this Video Cassette Recorder. Design alterations and additions, including, but not limited to circuit modifications and the addition of items such as auxiliary audio and/or video output connections, might alter the safety characteristics of this instrument and create a hazard to the user. Any design alterations or additions may void the manufacturer's warranty and may make you, the servicer responsible for personal injury or property damage resulting therefrom.

4. Observe original lead dress. Take extra care to assure correct lead dress in the following areas: a. near sharp edges, b. near thermally hot parts- be sure that leads and components do not touch thermally hot parts, c. the AC supply, and d. antenna wiring. Always inspect in all

areas for pinched, out-of-place, or frayed wiring. Do not change spacing between components, and between components and the printed circuit board. Check AC power cord for damage.

5. Components, parts, and/or wiring that appear to have overheated or are otherwise damaged should be replaced with components, parts, or wiring that meet original specifications. Additionally, determine the cause of overheating and/or damage and, if necessary, take corrective action to remove any potential safety hazard.

6. Product Safety Notice

Some electrical and mechanical parts have special safety related characteristics which are often not evident from visual inspection, nor can the protection they give necessarily be obtained by replacing them with components rated for higher voltage, wattage, etc. Parts that have special safety characteristics are identified by a (*) or (Δ) on schematics and parts list. Use of a substitute replacement that does not have the same safety characteristics as the recommended replacement part might create shock, fire, and/or other hazards.

Products safety is under review continuously and new instructions are issued whenever appropriate.

Electrostatically Sensitive (ES) devices

Some semiconductor (solid state) devices can be damaged easily by static electricity. Such components commonly are called *Electrostatically Sensitive (ES) Devices*. Examples of typical ES devices are integrated circuits and some field effect transistors and semiconductor "chip" components. The following techniques should be used to help reduce the incidence of component damage caused by static electricity.

1. Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed for potential shock reasons prior to applying power to the unit under test.

2. After removing an electrical assembly equipped with ES devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.

3. Use only a grounded-tip soldering iron to solder or unsolder ES devices.

4. Use only an anti-static type solder removal device. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ES devices.

5. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ES devices.

6. Do not remove a replacement ES device from its protective package until immediately before you are ready to install it. (Most replacement ES devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive material.)

7. Immediately before removing the protective material from the leads of a replacement ES device, touch the protective material to the chassis or circuit assembly into which the device will be installed.
CAUTION: Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.

8. Minimize bodily motions when handling unpackaged replacement ES devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ES device.)

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.

IMPORTANT SAFETY NOTICE
Components identified with the mark Δ have the special characteristics for safety when replacing any of these components. Use only the same type.

1-2. GENERAL INFORMATION

* VISS

. Index Search System

Index search system is the function of searching swiftly to previously designated points of interest on the tape using the index signal.

. Index Search

Searches the wanted index points and plays back for five seconds at each point.

. Intro-Scan

Skip the unwanted index points and plays back the selected point.

. Marking Index Points

In either play or record mode, press "MARK" button on remote to record index point on tape. The index indicator will blink on the display.

. Erasing Index Points

In play mode, press erase button and the unit will engage in visual search forward until an index point is reached, the index point will then be erased and the "INDEX" indicator will blink, the unit will then resume the play mode.

* DA 4 HEAD (Double Azimuth 4 Head)

This lets you see very fine picture during X2, search, still or slow mode.

* VPS (Video Program System) (OPTION)

V.P.S is a new system to prevent incorrect recordings being made due to a TV programme being postponed or cancelled.

* LTC (Linear Time Counter)

This function resets the counter when front loading starts after inserting a tape. Linear time counter indicates the elapsed time of the tape running increasing in seconds.

* OSD (On Screen Display) (OPTION)

The VCR modes will be indicated on the television screen in white characters.

* Unattended (timer) Recording

The programmable timer can be preselected up to one year in advance to record up to 8 preselected programmes. (NORMAL PROGRAMME or daily programme or weekly programme). The timer turns the VCR on and off and changes channels automatically.

* One touch Recording (O. T. R)

One touch recording (OTR) lets you record up to six hours without programming the timer. It also allows you to start (or continue) recording immediately or to delay recording up to 24 hours, when the recording is finished, the VCR will turn off automatically.

* F-Advance (Frame-Advance)

Push this button to give still frame, each successive press moves the picture on frame by frame. Then you can enjoy clear and distinct still picture.

* Automatic Digital Tracking

This function automatically optimizes a clearer picture in playback mode.

* Auto Channel Memory

This function remembers the channel automatically by the NV-RAM.

* GO TO

When the LTS (Linear Time Search) function is recalled as a circuit function, the go to search function advances the tape in the FF/REW to the time position requested.

Note : On insertion of tape into machine linear time counter is set to zero irrespective of position of tape.

* Search (JET)

If you push FF/REW in play for "reverse picture search" mode or "forward picture search" mode, picture search is performed 5/9 times as fast as play speed in SP/LP mode, and push FF/REW button again for JET picture search mode, it is performed 9/13 times as fast as play speed in SP/LP mode.

* X 2

If you push play button twice in normal playback mode, picture search is performed 2 times as fast as normal playback.

* Monitor

This button allows you to view the station that the VCR is tuned to whilst playing back a video tape. When the TV programme is displayed in this mode, the tape is still moving.

* Slow (Various Slow)

This is for adjustment of the slow speed operation in play back.

* Quick Start

This is to shorten the switching time from stop mode to play mode by having the tape deck fully loaded.

* SP/LP (Standard Play/Long Play)


This lets you record in either speed mode LP giving 8 hours from an E240 tape or SP giving 4 hours from an E 240 tape.

* LCD Remote Control (Liquid Crystal Display)

Allows setting of the clock and timer settings via handset.

1-3. OPERATING CONTROLS AND FUNCTIONS

1-3-1. FRONT VIEW



(VX/VI-1560)



- 1. POWER Button**
Push this button to turn VCR on and off.

Note: VCR turns on automatically when cassette is inserted.

- 2. EJECT Button**
Push this button to remove the cassette tape. Cassette can be ejected with the VCR power off as long as unit is connected to an AC outlet.

- 3. VIDEO CASSETTE COMPARTMENT**
Push the cassette gently into compartment until you feel automatic pull. Cassette can be inserted with the power off as long as unit is connected to an AC outlet.

- 4. REW (Rewind/ Reverse Picture Search) Button**
When the VCR is in stop mode, press REW to rewind the tape. When the VCR is in PLAY mode, press REW for high-speed reverse picture search. Press REW again for Jet search. (Push REW again to revert to reverse picture search, or push play to return to playback.)



(VX-1561)

- 5. PLAY/ X 2 Button**
Push this button to playback a pre-recorded tape. Press PLAY again to x2 playback. This function lets you view the picture at x2 speed with the sound mute.

Note: During x2 playback, the sound is muted and some noise may appear on your screen. If noise appear, adjust Trk +, - key.

- 6. FF (Fast Forward/Forward picture Search) Button**
When the VCR is in stop mode, press FF to forward the tape. When the VCR is in PLAY mode, press FF for high speed forward picture search. Press FF again for Jet search. (Push FF again to revert to forward picture search, or press play to return to playback.)

- 7. STOP Button**
Push this button to stop the tape during playback, recording, rewind or fast-forward.

- 8. P/S, F.ADV Button**
Push this button to stop the tape temporarily during playback or recording. Still picture will be shown during playback. Push PLAY to continue play, and push REC button to continue recording. In pause still mode, press the button to advance one frame at a time.

- 9. REC (RECORD) Button**
Push the REC button to start recording.

- 10. INFRARED REMOTE SENSOR**
Receives signal from infrared remote control.

11. FUNCTION DISPLAY INDICATORS

- 12. CHANNEL UP (Δ) / DOWN (∇) Buttons**
Push this button to select the channel what you wish to record or view on TV. Continuous holding of button's will change the channels.

- 13. MEMORY Button**
Push this button for the tape to stop automatically during rewind when the counter reaches about "00'00"00". In CH preset mode on pressing this button the VCR will automatically tune in all possible channels with sufficient signal strength.

- 14. COUNT/CH. CC Button**
Press this button to switch the real channel display to the tape counter display.

- 15. +, - Button**
In still mode, adjust this control to minimize vertical shaking on the TV screen. And press these buttons for clock setting, selection of a real channel, and MFT operation.

- 16. CLEAR/RESET Button**
Use to reset the counter to "00'00"00" or clear the clock setting data or delete stored channel.

- 17. INPUT SEL Button**
Select recording signal from the tuner or Audio/Video IN JACK.

- 18. SHIFT Button**
Press this button to go to the next step while you are doing clock setting, or the selection between CH and CC.

- 19. SEARCH Button**
Press this button for automatic channel search.

- 20. MFT Button**
Use to tune for fine picture. After pushing MFT button, use control (+) and (-) button to adjust fine tuning.

- 21. OTR START, OTR LENGTH Button**
The START and LENGTH buttons are used for OTR recording.

• Press the START Button to set OTR start time. Start can be delayed for up to 24 hours.

• Press the LENGTH button to set OTR length of recording.

- 22. TIMER Button**
Press this button after programming for unattended recording. Press this button to stop timer recording.

- 23. TRACKING +, - Buttons**
When you play a tape recorded on a different VCR, horizontal streaks (noise bars) may appear in the picture. Use these buttons to remove noise bars.

- 24. PICTURE CONTROL**
Use this control to soften or sharpen the VIDEO picture on the TV screen.

- 25. SPEED Button**
Press this button to select the speed of tape you to record.

1-3-2. MULTIFUNCTION DISPLAY



1. RECORDING INDICATOR * REC *

When recording starts, this indicator appears.

2. PLAY INDICATOR * PLAY *

When PLAY, SLOW, FPS, RPS mode, this indicator appears.

3. STATUS INDICATOR

Indicates * * mark when a video cassette is in tape compartment. And * --- * Marks indicate the status of VCR. When VCR is in PB, FF or FPS mode, * --- * marks goes clockwise as fast as linear time counter. In REW or RPS mode, * --- * marks goes counter clockwise. In still mode, * --- * marks are stopped.

4. O.T.R INDICATOR * OTR *

When One Touch Recording is set, this indicator appears.

5. TIMER INDICATOR

When TIMER recording is set, this indicator appears.

6. PROGRAM NUMBER * 1 - 8 *

This shows the program number for Timer Recording.

7. MEMORY INDICATOR * MEM *

When MEMORY button is set to ON, this indicator appears.

8. VPS INDICATOR VPS (OPTION)

Illuminates VPS when program recording is set, to VPS.

9. INDEX INDICATOR

This indicator blinks or lights when the INDEX button on remote control is pressed.

10. GO TO INDICATOR

When GO TO mode, this indicator lights.

11. DIGITAL CLOCK

Normally, the present time is displayed. In OTR mode, the start time is displayed.


12. MULTIFUNCTIONAL INDICATOR

This indicator displays clock/linear time counter/ OTR LENGTH.

13. SPEED INDICATOR * SP *, * LP *

This indicates the speed of tape.

1-3-3. REAR VIEW



1. AUDIO/VIDEO Socket

A 21-pin standardized audio/video input/output socket for the connection to a stereo TV if equipped with the same type of socket. The audio output can be selected with the AUDIO MONITOR SELECT switch.

2. ANTENNA IN Connector

Connect an aerial to this connector.

3. RF OUT Connector

Connect to the aerial connector of a TV receiver through the aerial cable (provided).


4. Test Signal Switch (TEST)

Set this S/W to ON when tuning your TV receiver for the video channel. A test signal in the form of two vertical white bars will be available.

5. RF CHANNEL PRE-SET

In some areas the pre-set RF output of your video cassette recorder may clash with a TV broadcast. If this occurs, turn this control using a small screw-driver clockwise or counter-clockwise. A new video channel has now been set and you will need to retune your television video channel to the new RF output.

1-3-4. REMOTE CONTROL (VX/VI-1560)



1. POWER Button

Press POWER for power on and off.

2. LCD PROG Button

Press this button to bring remote control to LCD programming for timer programming.

3. CLOCK SET Button

Press this button for clock setting.

4. GO TO Button

Press this button for GO TO function.

5. TRANS Button

Press this button to transfer LCD programme from remote control to your VCR's set.

6. 10 KEY Buttons (0 through 9)

Select any channel (whether it is in the tuner scanlist or not) by pressing two buttons. (Press * 0 *, and * 8 *, for channel 8.) These buttons are also used for setting the clock and timer programming.

7. UP (), DOWN () Buttons

In still mode, adjust this control to minimize vertical shaking on the TV screen. And press these buttons for selection of a real channel or MFT operation.

8. SEARCH Button

Press this button for automatic channel search.

9. COUNT/CH. CC Button

Press this button to switch the real channel display to the tape counter display and vice versa.

10. MEMORY Button

Using this button while rewinding the tape will stop automatically when the counter reaches about "00'00"00". In CH preset mode, when using this button the VCR will tune in all stations with sufficient signal strength.

11. CHANNEL UP () DOWN () Buttons

Push this button to select the channel what you wish to record or view on TV. Continuous holding of button's will change the channels.

12. TRACKING UP (Δ) DOWN (∇) Buttons
Press these buttons to remove noise bars in playback mode.

13. CLEAR/RESET Button

This is used to reset the counter to "00" "00" "00" or clear the clock setting data and timer program data or delete stored channel.

14. SHIFT Button

Press this button to go to the next step while you are doing clock setting, LCD programming, or the selection between CH and CC.

15. VPS Button (OPTION)

Press this button for VPS recording.

16. REW Button

To rewind the tape, Press this button while in stop mode. To view the speeded-up picture in the reverse direction for programme search, press this button in PLAY mode. Press REW again for Jet search.

17. PLAY/X2 Button

Push to playback a pre-recorded tape. Press PLAY again for 2 times playback.

18. F.F Button

To fast forward the tape, press this button while in the stop mode. To view the speeded-up picture in the forward direction for programme search, press this button in PLAY mode. Press F.F again for Jet search.

19. REC Button

Press REC button to begin recording.

20. P/S, F.ADV Button

Push this button to stop the tape temporarily during playback or recording. Still mode will be shown during playback. In pause still mode, press the button to advance one frame at a time.

21. STOP Button

If this button is pressed, VCR stops whatever the VCR is doing (record, playback, rewind, or fast forward).

22. SLOW, UP (Δ), DOWN (∇) Buttons
Press this button for various slow motion.

23. ERASE Button

Press ERASE to erase index signal.

24. INDEX Button

Press INDEX to turn on the electronic programme indexing feature. Display will prompt you to choose an index number or scan and play.

25. MARK Button

Press MARK to record index signal.

26. TIMER Button

Press this button after programming for unattended recording.

27. OTR START (Δ), LENGTH (∇) Buttons
These buttons are used for OTR recording.

28. INPUT SEL Button

Select recording signal from the tuner, Audio/Video IN JACK or simul cast.

29. MONITOR Button

Press this button when you want to know what is your TV channel during playback mode.


30. PROGRAMME Button

Push the button to enter timer program mode.

31. SPEED Button

Press this button to select the speed of tape you wish to record.

1-3-5. REMOTE CONTROL (VX-1561)



1. POWER Button

Press POWER for power on and off.

2. LCD PROG Button

Press this button to bring remote control to LCD programming for timer programming.

3. CLOCK SET Button

Press this button for clock setting.

4. GO TO Button

Press this button for GO TO function.

5. TRANS Button

Press this button to transfer LCD programme from remote control to your VCR's set.

6. 10 KEY Buttons (0 through 9)

Select any channel (whether it is in the tuner scanlist or not) by pressing two buttons. (Press "0", and "8", for channel 8.) These buttons are also used for setting the clock and timer programming.

7. +, - Buttons

In still mode, adjust this control to minimize vertical shaking on the TV screen. And press these buttons for selection of a real channel or MFT operation.

8. SEARCH Button

Press this button for automatic channel search.

9. COUNT/ CH. CC Button

Press this button to switch the real channel display to the tape counter display and vice versa.

10. MEMORY Button

Using this button while rewinding the tape will stop automatically when the counter reaches about "00" "00" "00". In CH preset mode, when using this button the VCR will tune in all stations with sufficient signal strength.

11. CHANNEL UP (Δ) DOWN (∇) Buttons
Push this button to select the channel what you wish to record or view on TV. Continuous holding of button's will change the channels.

12. TRACKING UP (Δ) DOWN (∇) Buttons
Press these buttons to remove noise bars in playback mode.

13. CLEAR/RESET Button
This is used to reset the counter to 00:00:00 or clear the clock setting data and timer program data or delete stored channel.

14. SHIFT Button
Press this button to go to the next step while you are doing clock setting, LCD programming, or the selection between CH and CC.

15. VPS Button (OPTION)
Press this button for VPS recording.

16. REW Button
To rewind the tape, Press this button while in stop mode. To view the speeded-up picture in the reverse direction for programme search, press this button in PLAY mode. Press REW again for Jet search.

17. PLAY/X2 Button
Push to playback a pre-recorded tape.
Press PLAY again to 2 times playback.

18. F.F Button
To fast forward the tape, press this button while in the stop mode. To view the speeded-up picture in the forward direction for programme search, press this button in PLAY mode. Press F.F again for Jet search.

19. REC Button
Press REC button to begin recording.

20. P/S, FADV Button
Push this button to stop the tape temporarily during playback or recording. Still mode will be shown during playback. In pause still mode, press the button to advance one frame at a time.

21. STOP Button
If this button is pressed, VCR stops whatever the VCR is doing (record, playback, rewind, or fast forward).

22. SLOW Button, +, - Buttons
Press this button for various slow motion.

23. ERASE Button
Press ERASE to erase index signal.

24. INDEX Button
Press INDEX to turn on the electronic program me indexing feature. Display will prompt you to choose an index number or scan and play.

25. MARK Button
Press MARK to record index signal.

26. TIMER Button
Press this button after programming for unattended recording.

27. OTR START, LENGTH Buttons
These buttons are used for OTR recording.

28. INPUT SEL Button
Select recording signal from the tuner, Audio/Video IN JACK or simul cast.

29. MONITOR Button
Press this button when you want to know what is your TV channel during playback mode.

30. PROGRAM Button
Push the button to enter timer program mode.

31. SPEED Button
Press this button to select the speed of tape you wish to record.

32. DISPLAY Button (OPTION)
Press this button to display or remove OSD characters.

1-4. CLEANING AND LUBRICATION

1-4-1. CLEANING TAPE MECHANISM

Periodic cleaning is necessary to insure continued excellent performance of the tape mechanism. To clean the following parts, patch and solvent are available.

1. Capstan shaft.
2. All idler wheels.
3. All tape guide posts.
4. Supply and take-up reels.
5. Pinch roller.
6. Capstan belt.
7. Capstan motor pulley.

To clean video heads, full erase head, and audio/control (A/C) head, use only head cleaning kit and solvent.

Note: When cleaning video heads, move the cleaning stick in the direction of head rotation. Wiping in a vertical direction may damage the heads.

1-4-2. LUBRICATION TAPE MECHANISM

The tape transport mechanism is properly lubricated at the factory. In normal use cycles, and with average environmental conditions, additional lubrication should not be required during the first year of operation.

Depending on the frequency of use and environmental conditions, periodic lubrication may be required. When relubricating, remove old lubricant first, then sparingly apply new lubricant. (Excessive lubricant may be transferred to other assemblies causing malfunction).

Use grease on the following parts every 1,000 hours of operations. (See exploded view for location.)

1. Between base pole assembly (L,R) and main base
2. Pinch roller base, Cam.
3. Gear master cam.
4. Gear E/J drive.
5. Gear 1/D "L,R".
6. Base pole edge.
7. Slide main brake.
8. Bracket E/J drive.
9. Sector gear.

Oil may be required for the following parts after 1,000 hours of operation. (See exploded view for location.)

Main base

1. Arm tension mould.
2. Shaft reel disk "L,R" mould.
3. Shaft gear worm wheel.

Other parts which are not listed above do not be required lubrication, except when parts are replaced. Use appropriate oil or grease as indicated on exploded view.

1-5. ABBREVIATIONS

2X : Double
4.43MHz : Colour Sub Carrier
ACC : Automatic Colour Control
ACK : Automatic Colour Killer
ADD : Adder
AFC : Automatic Frequency Control
AFT : Automatic Fine Tuning
AGC : Automatic Gain Control
AL : Always
ALC : Automatic Level Control
AMP : Amplifier
APC : Automatic Phase Control
AUX : Auxiliary

BATT : Battery
BD : Burst Demphasis
BE : Burst Emphasis
BH : Power Supply for Selecting VHF High Band
BL : Power Supply for Selecting VHF Low Band
BPF : Band Pass Filter

C.FG : Capstan Frequency Generator
C.SYNC : Composite Syne
CAFC : Capstan Auto Frequency Control
CAPC : Capstan Auto Phase Control
CATV : Cable TV
CAR : Carrier
CAP : Capstan
CCD : Charge Coupled Devices
CH : Channel
CHAR. : Character
CHROMA : Chrominance
CM : Capstan Motor
COMP : Comparator
CST : Cassette
C-ERR : Capstan Error
CTL : Control
C.PG : Capstan Pulse Generator
CUREMPH : Current Emphasis

D.FG : Drum Frequency Generator
D.O.C : Drop Out Compensator
D.PG : Drum Pulse Generator
D/A : Digital-to-Analog
D/C : Dark/Clip
D.AFC : Drum Auto Frequency Control
D.APC : Drum Auto Phase Control
DE-EMPH : De-Emphasis
DET : Detector
DEV : Deviation
DLYD : Delayed
DM : Drum Motor
DEMOD : Demodulator
D.D : Direct Drive

E-E : Electronic-to-Electronic
EMPH : Emphasis
ENV : Envelope
EQ : Equalizer

FADV : Frame Advance
F-V : Frequency to Voltage Converter
F.FWD : Fast Forward
FH : Frequency Horizontal
FG : Frequency Generator
FM : Frequency Modulator
FSC : Frequency Sub Carrier
FWD : Forward
FC : Frequency Center
FL : Frequency Low

GEN : Generator
GND : Ground

HPF : High Pass Filter

IF : Intermediate Frequency
IR : Infrared Receiver

LED : Light Emitting Diode
LIM : Limiter
LPF : Low Pass Filter
LUMA : Luminance
LCD : Liquid Crystal Display
LNR : Linear

MIX : Mixer
MM : Monostable Multivibrator
MTS : Multi Sound Television System
MEM : Memory

N.C : No Connection
NORM : Normal

OSC : Oscillator
OTR : One Touch Recording
OSP : On Screen Programme
OSD : On Screen Display

PB : Play Back
P.C : Power Control
PG : Pulse Generator
PIF : Picture Intermediate Frequency
PLL : Phase Lock Loop
PRG : Programme

PWM : Pulse Width Modulation
PWR : Power
PS : Pause/Still
PD : Power Detector

REG : Regulator
REC : Record
REC.SAF : Record Safety
REW : Rewind
RF : Radio Frequency
REV : Reverse
RECT : Rectifier
REF : Reference

SC : Simul-Cast
SC : Sub-Carrier
SCK : Shift Clock
SDA : Serial Data
SIF : Sound Intermediate Frequency
SP : Standard Play
SW25Hz : Head Switching Pulse
SYNC : Synchronizing Signal
SYSCON : System Control
STB : Strobe
SI : Serial Input
SO : Serial Output
SW : Switch

TP : Test Point
TRK : Tracking

UL : Unloading

VT : Tuning Voltage
VP : Vertical Lock pulse
V-REF : Voltage Reference
V-SYNC : Vertical Sync
VCO : Voltage Controlled Oscillator
VCR : Video Cassette Recorder
VIF : Video Intermediate Frequency
VPS : Video Programming System
VHS : Video Home System
VXO : Voltage Controlled Crystal Oscillator
VSS : Voltage Supply Source
VISS : VHS Index Search System

W/C : White/Clip
W/D : White/Dark

Y : Luminance

uP : Microprocessor

2. DISASSEMBLY

2-1. INSTRUMENT DISASSEMBLY

2-1-1. Top Cabinet Removal




Fig. 1 Top Cabinet Removal

1. Remove three (3) screws located at the rear of the top cabinet.
2. Carefully lift the back of the top cabinet and slide it to the rear to remove.

2-1-2. Bottom Cover Removal




Fig. 2 Bottom Cover Removal

1. Remove one (1) screw holding bottom cover.

2-1-3. Front Panel Removal

1. Remove the top cabinet. (Fig.1)
2. Remove one (1) screw from the top of the front panel.
3. Release four (4) tabs from the front panel.
4. Release three (3) tabs from the bottom of the front panel.
5. Tilt the front panel forward to remove.




Fig. 3 Front Panel Removal

2-1-4. Main Circuit Board Removal




Fig. 4 Main Circuit Board removal

1. Follow the procedure for removing top cabinet. (Fig.1)
2. Remove two (2) screws from the frame.
3. Release four (4) tabs from the frame.
4. Disconnect two (2) connectors (CN205, CN206) between the main circuit board and timer circuit board.

2-1-5. Function Switch Circuit Board Removal




Fig. 5 Function Switch Circuit Board Removal

1. Follow the procedure for removing the panels. (Figs. 1 and 3)
2. Release tabs from the frame. (Fig.5)
3. Remove four (4) tabs holding the function switch circuit board.
4. Disconnect CN701 from the timer circuit board.

2-1-6. Timer Input Key Circuit Board Removal




Fig. 6 Timer Input Key Circuit Board Removal

1. Follow the procedure for removing the panels. (Fig.1 and 3)
2. Release two (2) tabs holding circuit board from the frame.

2-1-7. Pre-Amp Circuit Board Removal




Fig. 7 Pre-Amp Circuit Board Removal

1. Follow the procedure for removing the top cabinet (Fig.1), bottom cover (Fig.2) and front panel (Fig.3).
2. Remove two (2) screws holding the Pre-Amp from the frame.
3. Disconnect the one (1) connector on the Pre-Amp circuit board.
4. Pull out the Pre-Amp ass'y in the direction of the arrow and then release shield case.

2-1-8. Regulator Circuit Board Removal




Fig. 8 Regulator Circuit Board Removal

1. Follow the procedure for removing the top cabinet (Fig.1)
2. Remove the regulator cover and three (3) screws from the frame.
3. Disconnect one (1) connector (CN101) on the main circuit board.
4. Taking care of the cable assemblies, lift up the regulator circuit board upward to remove.

2-2. MECHANICAL DISASSEMBLY

Tape Transport Mechanism Identification (Top Side)




Fig. 9 Tape Transport Mechanism-Top View

- | | |
|-----------------------------|-----------------------|
| 1. F/E HEAD | 13. SUB BRAKE "R" |
| 2. SUPPLY ROLLER | 14. REVIEW ARM ASS'Y |
| 3. POLE BASE "L" ASS'Y | 15. REEL DISK (R) |
| 4. CYLINDER ASS'Y | 16. LED ASS'Y |
| 5. POLE BASE "R" ASS'Y | 17. SUB IDLER ASS'Y |
| 6. A/C HEAD ASS'Y | 18. REC S/W SPRING |
| 7. CAM ADJUST | 19. REEL DISK (L) |
| 8. PINCH ROLLER LEVER ASS'Y | 20. REC S/W LEVER |
| 9. MASTER CAM GEAR | 21. SUB BRAKE "L" |
| 10. L/D UNIT ASS'Y | 22. TENSION ARM ASS'Y |
| 11. P.C.B JOINT ASS'Y | 23. TENSION SPRING |
| 12. BRAKE LEVER CAM ASS'Y | |

(Bottom Side)




Fig. 10 Tape Transport Mechanism-Bottom View

- | | |
|-----------------------------|----------------------------|
| 1. EJECT DRIVE BRACKET | 9. SUB SPRING "L" |
| 2. D.D CAPSTAN BRAKE SPRING | 10. MAIN BRAKE "L" |
| 3. D.D CAPSTAN BRAKE | 11. MAIN BRAKE SLIDE ASS'Y |
| 4. SECTOR GEAR ASS'Y | 12. CLUTCH ASS'Y |
| 5. LOADING GEAR "R" ASS'Y | 13. REEL P.C.B ASS'Y |
| 6. CYLINDER MOTOR | 14. D.D CAPSTAN MOTOR |
| 7. LOADING GEAR "L" ASS'Y | 15. SUB SPRING "R" |
| 8. TENSION CONTROL LEVER | |




Fig. 11 F/L Housing Assembly Identification

2-2-1. Housing Assembly Removal

1. Follow the procedure for removing the cover (See Figs. 1 to 3).
2. Disconnect the housing sensor connector from the PWB Deck Joint.
3. Remove two (2) screws holding the housing assembly and the Main Base.
4. Push the housing assembly in the direction of arrow A and then lift up in the direction of arrow B.




Fig. 12 Housing Assembly Removal

2-2-2. PWB Sensor (S) Assembly Removal

1. Push the wire toward A, B arrows and then remove.
2. Push apart clips as shown in C direction and remove P.C.B.




Fig. 13 PWB Sensor (S) Assembly Removal

2-2-3. PWB Sensor (E) Assembly Removal

1. Push apart clip as shown in direction A and remove P.C.B. in direction C.




Fig. 14 PWB Sensor (E) Assembly Removal

2-2-4. Sub Assembly Removal

1. Remove two (2) screws holding the upper chassis and remove the ground wire assembly and the ground plate top.
2. Lift the upper chassis toward A.
3. Lift the assembly cassette holder toward E.
4. Push the eject slide toward E to the end, lift it in the direction of arrow C.
5. Release clip on right side of chassis in direction D and remove the Joint Gear.




Fig. 15 Sub Assembly Removal

2-2-5. Side Arm Assembly Removal

1. Release the clip as shown in A.
2. Lift chassis right as shown in C.
3. Release the clip as shown in D.
4. Release the clip on left chassis, same as in step 2.
5. Remove left side chassis as shown in F.




Fig. 16 Side Arm Assembly Removal

2-2-6. Arm Gear Removal

1. Remove eject spring by prying out center.
2. Remove spring tension arm (R) from the hook of side arm (R).
3. Remove the arm gear.




Fig. 17 Arm Gear Removal

2-2-7. Cassette Holder Assembly Removal

1. Remove the spring the holder L/R and lever LID L/R and remove the lever LID.
2. Remove the key cassette from the side holder (R) and remove the spring key cassette from the key cassette.
3. Lift the plate cassette upper toward A after taking off the hook of side holder L/R.
4. Lift up the side holder L/R from the cassette holder.




Fig. 18 Cassette Holder Assembly Removal

2-2-8. Side Chassis (L) Assembly Removal

1. Release light shutter spring from side chassis.
2. Remove light shutter after releasing tab as shown in A.
3. Lift up the earth plate to remove.
4. Remove the mask cam lever in the direction of arrow B from the side chassis (L).




Fig. 19 Side Chassis (L) Assembly Removal

NOTE: To re-assemble reverse procedure.

2-2-9. Joint Gear, Arm Gear and Eject Slide Assembly

1. Assemble the assembly point of the joint gear and the arm gear.
2. Assemble the joint gear with the eject slide as Fig.20.




Fig. 20 Joint Gear, Arm Gear and Eject Slide Assembly

2-2-10. Deck Assembly and Assembly of F/L Housing Assembly





Fig.21 Housing Assembly Point




Fig.22 Mechanism Chassis Assembly Removal

NOTE: Perform this procedure with mechanism in the eject position.

1. Pull the eject slide gear and assemble the point of E/J Drive Gear and E/J Slide Gear. (Fig. 21)
2. While holding cassette holder in the eject position, align the A and B assembly points as shown in Fig. 22.
3. Tighten two (2) screws.

NOTE: Recheck A and B position after reinstallation, if incorrect repeat above.

* Operating the VCR without Housing Assembly.

1. Connect a jumper to short circuit momentarily between pin 1 (ground) and pin 3 (start sensor) of CN6202 on DECK JOINT.
2. After loading, function key is available to be used to select desired mode.

* Operating the VCR without inserting a cassette tape.

1. Remove the Housing upper chassis.
2. Push the cassette holder, while hiding the both sensors of LED IR.
3. After loading, function key is available to be used.

2-2-11. Cylinder Assembly Removal

CAUTION: Take extreme care when removing the upper cylinder. Do not touch the video head tips located at the upper cylinder during servicing.

Follow the Procedure for Removing

1. Remove the top cover. (See Fig. 1)
2. Remove the bottom cover. (See Fig. 2)
3. Remove the cylinder ass'y from the main base.
4. Remove two (2) screws from the upper cylinder ass'y.
5. Unsolder PWB-Upper cylinder and then lift upper cylinder.
6. Remove screw from lower cylinder and detach TR holder ass'y.
7. Remove two (2) screws from the motor rotor, then remove it.
8. Remove three (3) screws from the motor stator and remove it.




Fig. 23 Cylinder Assembly Removal

2-2-12. Upper Cylinder Removal

1. Unsolder the PWB upper Cylinder from the upper cylinder ass'y.
2. Remove two (2) screws from the upper cylinder ass'y and remove it.




Fig. 24 Upper Cylinder Removal




Fig. 25 PWB Upper Cylinder

• Upper Cylinder Assembly

1. Align the head tip of Green PCB on upper cylinder bottom side (Fig. 26) to slit of rotary trans on lower cylinder (Fig. 27).
2. Tighten two (2) screws.




Fig. 26 Upper Cylinder Bottom View




Fig. 27 Lower Cylinder Top View

2-2-13. Lower Cylinder Removal

1. Lift up the lower cylinder from the cylinder base.

NOTE: Align cylinder base pin before reinstalling.




Fig. 28 Lower Cylinder Removal

2-2-14. Cylinder Motor Removal

1. Remove two (2) screws from the motor rotor, then remove rotor.




Fig. 29 Cylinder Motor Removal

NOTE: Mark rotor position to insure correct phase orientation upon reinstallation.

2. Remove three (3) screws from the motor stator and remove it from the lower cylinder.

• Motor rotor Assembly

1. Tighten 2 screws while fixing the hole of cylinder bush and rotor (Fig. 30)




Fig. 30 Motor Rotor Assembly

2-2-15. Cylinder Assembly Removal from Main Base

1. Remove three (3) screws securing the cylinder base and main base.
2. Lift the cylinder base to remove.




Fig. 31 Cylinder Assembly Removal

2-2-16. Loading Assembly and E/J Drive Bracket Removal

1. Remove the top cabinet. (See Fig. 1)
2. Remove the screw from the PWB joint, and then lift up the PWB joint.
3. Remove three (3) screws of loading unit assembly.
4. Lift up the loading unit assembly.
5. Remove two (2) screws securing eject drive bracket from the side of main base.
6. Lift to remove.




Fig. 32 Loading Assembly and E/J Drive Bracket Removal

2-2-17. Brake Lever Cam Assembly Removal

1. Remove the slit washer from pinch roller stud.
2. Lift up the brake lever cam assembly.




Fig. 33 Brake Lever Cam Assembly Removal

2-2-18. Worm Gear Wheel, Master Cam and Eject Drive Gear Removal

1. Lift up the worm gear wheel.
2. Lift up the eject drive gear.
3. Lift up the master cam gear.




Fig. 34 Worm Gear Wheel, Master Cam and Eject Drive Gear Removal

2-2-19. Pinch Roller Lever Assembly Removal

1. Lift up the pinch roller assembly.
2. Remove the spring pinch roller.




Fig. 35 Pinch Roller Lever Assembly Removal

2-2-20. Sector Gear Removal

1. Remove two (2) slit washers securing sector gear stud and loading gear "R" from the bottom side of main base.
2. Place loading gears in eject position. Lift up the sector gear.




Fig. 36 Sector Gear Removal

2-2-21. Loading Gear L/R Removal

1. Release the tab securing the loading gear ass'y. to the loading gear arm from the bottom.
2. Lift up the loading gear L/R to remove.




Fig. 37 Loading Gear L/R Removal

2-2-22. Reel Disk "R" Removal

1. Release locking tab on the beneath of the sub brake "R".
2. Remove the sub brake "R".
3. Remove the slit washer.
4. Lift up the reel disk.
5. Remove the plain washer.




Fig. 38 Reel Disk "R" Removal

2-2-23. Reel Disk "L" Tension Band & Tension Arm Removal

1. Take off the tension arm spring.
2. Align tension arm adjustment with slot in the tension band, then pull up to remove.
3. Release two tabs on tension arm.

4. Remove the tension band.
5. Remove slit washer.
6. Lift up the reel disk "L" after removing the sub brake "L" in the direction of arrow.
7. Remove the plain washer.




Fig. 39 Reel Disk "L" Tension Band & Tension Arm Removal

2-2-24. Sub Brake L/R and REC Lever Switch Removal

1. Remove the sub brake spring "L". (Refer to the main brake slide removal)
2. Remove the sub brake spring "R". (Refer to the main brake slide removal)
3. Remove the REC lever switch.
4. Release tab from beneath chassis. Lift up the sub brake L/R.
5. Release tab from beneath chassis. Remove the REC lever switch.




Fig. 40 Sub Brake L/R and REC Lever Switch Removal

2-2-25. Main Brake L/R and Tension Lever Control Removal

1. Remove capstan belt.
2. Remove slit washer securing clutch ass'y.
3. Release main slide yellow spring by unhooking from supply reel tab.
4. Release four (4) tabs and remove main slide.
5. Release tab and remove the tension lever control. Refer to Fig. 41.
6. Release tab and remove main brake left/right.




Fig. 41 Main Brake L/R and Tension Lever Control Removal

2-2-26. Capstan Motor and Capstan Motor Brake Removal

1. Remove the D.D capstan brake spring. Turn assembly to release tab.
2. Lift up the D.D capstan brake to remove.
3. Remove capstan cable from PCB.
4. Remove three (3) screws holding the capstan motor from the main base.
5. Remove the capstan motor belt from the capstan motor pulley and the clutch ass'y. Remove motor.




Fig. 42 Capstan Motor and Capstan Motor Brake Removal

2-2-27. Idler Clutch and Shift Lever Removal

1. Remove the slit washer.
2. Remove the clutch assembly.
3. Pull the shift lever up toward vertical, push forward chassis back, then up to remove.




Fig. 43 Idler Clutch and Shift Lever Removal

2-2-28. Main Brake Slide Removal

1. Remove the sub "L" spring.
2. Remove the main slide spring from supply reel tab.
3. Lift up the main brake slide after releasing the securing tabs.
4. Remove the idler shift spring after releasing the securing tabs.




Fig. 44 Main Brake Slide Removal

2-2-29. PWB Reel Removal

1. Disconnect the lead connector assembly.
2. Remove the two (2) screws.
3. Lift up the PWB reel.

NOTE: When reinstalling PWB, pull REC safety switch arm back.




Fig. 45 PWB Reel Removal

2-2-30. Idler Sub Assembly Removal

1. Remove the slit washer.
2. Lift up the idler sub assembly.




Fig. 46 Idler Sub Assembly Removal

2-2-31. Assembly LED Removal

1. Disconnect the lead connector assembly.
2. Remove the one (1) screw.
3. Lift up the LED holder.




Fig. 47 Assembly LED Removal

2-2-32. Worm Gear Positioning (Eject Mode)

- Assemble in the eject mode, rotate worm gear full counter clockwise.

2-2-33. Pinch Roller Assembly and Master Cam Gear Assembly

1. Fasten pinch roller ass'y. to pinch roller stud.
2. Reinstall master cam gear with pinch roller ass'y. in the eject mode. Refer to Fig. 48.

NOTE: Align the assembly pin with the Master Cam gear alignment hole.



Fig. 48 Pinch Roller Assembly and Master Cam Gear Assembly

2-2-34. Brake Cam Lever, Eject Drive Gear and Master Cam Gear Assembly

1. Assemble the brake cam ass'y. on the pinch lever stud as in Fig. 49.
2. Assemble master cam gear with the brake cam lever ass'y. in eject mode.
3. Assemble gear E/J (eject) drive to stud as shown in Fig. 49, secure with slit washer.

NOTE: Align arrows on master cam & eject drive gear.





Fig. 49 Brake Cam Lever, Eject Drive Gear and Master Cam Gear Assembly

2-2-35. Ass'y Loading Unit and Master Cam Gear Assembly

1. Align master cam hole with chassis hole.
2. Align program switch arrows, push brake tension lever to align tracking pin as shown in Fig. 50.
3. Align master cam & eject drive gear arrows.
4. Reinstall loading gear ass'y.





Fig. 50 Ass'y Loading Unit and Master Cam Gear Assembly

2-2-36. Sector Gear and Loading Gear Assembly

1. Reinstall the loading gear L/R assemblies in the eject mode while align the timing marks. (Fig. 51)
2. Install sector gear and align with timing mark on the supply side loading gear. (Fig. 52)
3. Secure with slit washers.




Fig. 51 Loading Gear L/R Assembly point





Fig. 52 Sector Gear and Loading Gear Assembly

2-2-37. Pole Base Removal

1. Loosen one (1) screw from bottom of pole base.
2. Slide and remove retainer clips.
3. Remove pole base ass'y.
4. Install in reverse order.




Fig. 53 Pole Base Removal

2-2-38. Audio Control Head Assembly Removal

1. Remove the nylon nut holding A/C head stud.
2. Remove three (3) screws and spring.
3. Lift up the A/C head assembly.
4. Remove A/C head holder from the stud.
5. Lift up the spring torsion A/C.




Fig. 54 Audio Control Head Assembly Removal

2-2-39. Review Arm Assembly Removal

1. Remove the nylon nut holding the review arm stud.
2. Lift up the washer plain.
3. Lift up the review arm assembly.
4. Remove the review arm spring.




Fig. 55 Review Arm Assembly Removal

2-2-40. Full Erase Head Removal

1. Disconnect the lead connector assembly from the Full Erase Head.
2. Remove the screw holding the Full Erase Head and the main base.
3. Lift up the Full Erase Head.




Fig. 56 Full Erase Head Removal

3. MECHANICAL ADJUSTMENT

3-1. MECHANICAL ADJUSTMENT TOOLS

NO	JIG ITEM	CODE NO.	SPECIFICATION	DESCRIPTION	SKETCH NO.
1	TORQUE HEAD GAUGE	68140-100-100	COMMON ; LONG	; Use for torque adjustment of Take up / Supply Reel.	A
2	ALIGNMENT TAPE	68140-100-207 68140-100-208 68140-100-209 68140-100-210 68140-100-211	PAL ; SR 1-2 PAL ; SR 2-2 PAL ; SVJ -2 PAL ; SHR 2-2 PAL ; SHVJ -2	; LION PATTERN ; 6KHz ; COLOUR BAR ; 1KHz ; PROGRAMME (MONO) ; COLOUR BAR (Hi-Fi) ; L-1KHz, R-400Hz ; PROGRAMME (Hi-Fi)	B
3	BACK TENSION CASSETTE TAPE	68140-100-105	COMMON	; Use for back tension adjustment of Supply reel.	C
4	MASTER PLANE AND REEL DISK HEIGHT JIG	68140-110-101	G-10	; Use for height Adjustment of Reel Disk and Deck plate.	D
5	SERVICE JIG KIT	68140-100-301	UPPER DRUM REPLACING JIG	Use for upper drum replacement.	E(A)
			DRIVER HANDLE	Use for connection with each driver.	E(B)
			CAP.ADJ. DRIVER	; Use for CAP nut Adjustment and X-position Adjustment with A/C Head movement.	E(C)
			(+) (-) DRIVER	; Use for screw Adjustment and Audio Azimuth Adjustment.	E(D-G)
			N3 BOX DRIVER	; Use for A/C Head or Roller supply review arm replacement and Tape transport Adjustment.	E(H)
			HEX WRENCH (0.9mm) HEX WRENCH (1.5mm) HEX WRENCH (2.0mm)	; Use for Guide Roller set screw fastening. ; Use for AudioAzimuth Adjustment (Differ from item) ; Use for Drum bush and driver replacement.	E(I)
			CERAMIC DRIVER	; Use for Electrical Adjustment.	E(J)
			HOUSING ASSEMBLING JIG	; Use for Housing Assembly. (Refer to service manual for further information)	E(K)
			TRANSPORT MECHANISM ADJUSTING DRIVER	; Use for height adjustment of Guide Roller for Envelope linearity adjustment.	E(L)

3-3. TAPE TRANSPORT SYSTEM

Note :
The tape transport system has been adjusted precisely in the factory. Alignment is not necessary except for the followings :

- Noises observed on the screen.
- Tape damage.
- Parts replacement in the tape transport system.

3-3-1. Location of tape transport adjustment. (Adjustment reference)

Lower flange height of tape guide is used as the basic reference for the transport adjustment. To keep height of the tape guide, do not apply excessive force onto the main base to prevent deformation.




Fig. 1 Location of tape transport adjustment





Fig. 2 Tape travel diagram

A : TORQUE HEAD GAUGE




B : ALIGNMENT TAPE




C : BACK TENSION CASSETTE TAPE



D : MASTER PLANE AND REEL DISK HEIGHT JIG



E : SERVICE JIG KIT



(A) UPPER DRUM REPLACING JIG

(B) DRIVER HANDLE

(C) CAP ADJ. DRIVER

(D-G) (+) (-) DRIVER

(H) NABOX DRIVER

(I) HEX WRENCH (0.9mm)
HEX WRENCH (1.5mm)
HEX WRENCH (2.0mm)

(J) CERAMIC DRIVER

(K) HOUSING ASSEMBLING JIG

(L) TRANSPORT MECHANISM
ADJUSTING DRIVER

3-3-2. Tape transport system adjustment

1) Pre-adjustment

When the part (s) are replaced, perform required adjustments by referring to procedures for the tape transport system. When the part (s) are replaced, the tape path may be changed. First run a E-180 tape and make sure excessive tape wrinkle does not occur at each tape guide.

1. If tape wrinkle is observed at the S, T-guide rollers, turn the S, T-guide rollers until wrinkle disappears.
2. If the tape wrinkle is still observed at the tape guide, perform the tilt adjustment of the A/C head.

2) Adjustment procedures

1. A/C Head Assembly Adjustment

a. A/C tilt adjustment

1. Play back a E-180 tape and observe running condition of the tape at the lower flange of tape guide.
2. Adjust the A/C tilt adjusting screw until tape wrinkle is caused at the lower flange of tape guide as shown in Fig.3 (A).
3. Turn the A/C tilt adjusting screw counterclockwise until the tape travels along the lower flange as shown in Fig. 3 (B).




Fig. 3 Tape guide check

b. Audio Azimuth Adjustment

1. Load alignment tape (SR1-2: 6KHz) and playback the 6KHz signal.
2. Connect channel-1 scope probe to TP501.
3. Adjust screw (B) vertically, to achieve maximum audio level.
4. Adjust screw (C) and hex nut to achieve maximum audio level.




Fig. 4 A/C head assembly

c. Audio head height adjustment

1. Run the alignment tape SR2-2 in the playback mode.
2. Observe surface of the audio head using a dental mirror.
3. Turn the A/C height adjusting nut until the gap of lower tape edge and the lower edge of the control head is about 0.25mm shown in Fig. 5.
4. Play back the 1KHz audio signal in the alignment tape and adjust the head height for maximum audio output.




Fig. 5 Head Height

d. A/C Head Position Pre-adjustment


1. Play back the SP mode, video envelope on the SR1 alignment tape.
2. Adjust the CAM adjust for maximum video envelope output make sure the tracking control is set at its center position.

2. Linearity adjustment (S, T-guide rollers adjustment)

1. Play back the mode, video envelope on the SR 1-7 alignment tape.
2. Observe the video envelope signal on an oscilloscope triggered by the video switching pulse.
3. Make sure the video envelope waveform (in its minimum output) meets the specification shown in Fig. 6. If it is not, adjust as follows:

Note:

- a = maximum output of the video RF envelope
- b = minimum output of the video RF envelope at the entrance side
- c = minimum output of the video RF envelope at the center point
- d = minimum output of the video RF envelope at the exit side



$$a, b, c, d / a \geq 0.83$$

Fig. 6 Envelope Waveform Adjustment

4. If the section A in Fig. 7 does not meet the specification, adjust the S-guide roller up or down.
5. If the section B in Fig. 7 does not meet the specification, adjust T-guide roller up or down.




Fig. 7 Adjustment Points

6. After completion of the adjustment (s), vary tracking control from one end to the other and make sure video envelope variations are almost flat.
7. If the envelope varies as shown in Fig. 8 adjustment of the S, T-guide rollers may be upset, so perform the adjustment again.



Fig. 8 Abnormal variation of the waveform

3. A/C Head Assembly Fine Adjustment

a. Tape wrinkle check at the lower flange of tape guide.

1. If tape wrinkle is observed at the lower flange of tape guide, adjust the A/C tilt adjusting screw counter clockwise as shown in Fig.3 until the wrinkle disappears.
2. If a gap is observed between the lower flange of tape guide and the lower edge of tape, adjust the A/C tilt adjusting screw clockwise until the tape travels along the lower flange.

Note:

This adjustment should be done using a beginning part of E-180 tape.

b. Azimuth Adjustment

1. Play back the SP mode, 6KHz audio signal on the alignment tape SR1-2.
2. Adjust the A/C azimuth adjusting screw for maximum audio output as shown in Fig. 4.

c. Head height adjustment

1. Play back the alignment tape (SR 2-2).
2. Adjust the A/C head height adjusting nut for maximum audio output.

d. A/C head position adjustment

1. Play back the mode, white video envelope signal on the alignment tape (SR1-2).
2. Trigger the oscilloscope with the video switching pulse and observe the video envelope waveform.
3. Turn the cam adjust slowly and fix the taper nut at the position where the video envelope reaches a peak level.

4. Review Arm Guide Lever Adjustment





Fig. 9 Review Arm Guide Lever Adjustment

1. Set the VCR to FPS mode with E-180 tape (at beginning portion) loaded. Switch the FPS mode to review mode, after some tape has been wound into T-reel table.

3-2. TAPE TRANSPORT SYSTEM ADJUSTMENT FLOW CHART



4. Reel Disk Height Adjustment

1. Set the jig for reel disk height to the reel disk L,R as shown in Fig.14
2. The needles of L,R should be located within ± 0.05 .




Fig. 14 Reel disk height

4. ELECTRICAL ADJUSTMENTS

4-1. PREPARATION

Electrical adjustments are required after replacing circuit components and certain mechanical parts. It is important to perform these adjustment only after all repairs and replacements have been completed. Also, do not attempt these adjustments unless the proper equipment is available.

4-1-1. Required test equipment

1. Colour television or monitor
2. Oscilloscope: wide-band, dual-trace, triggered delayed sweep.
3. Frequency counter.
4. Audio oscillator.
5. Audio voltmeter.
6. Digital voltmeter.
7. Signal generator: RF/IF sweep/marker.
8. Signal generator: PAL colour bar, 100% White.
9. Recording tape.
10. Alignment tapes: SR2-2, SR1-2.




Fig. 3 Color bar signal waveform




Fig. 4 Color bar pattern




Fig. 1 Tape




Fig. 2 Color bar signal of pattern generator

2. Check tape wrinkle at the upper and lower flange of tape guide. Adjust the review arm so that the tape runs along the lower flange.
3. Set the VCR to the FPS mode again and make sure the tape is not twisted between the capstan and the review arm guide. If it is twisted again, adjust the review arm guide height and the adjustment in step 1.

5. Check For Transitional Operation From Review to Play

Check transition from review mode to play mode, using a pre-recorded tape, make sure the entrance side of envelope comes to an appropriate steady state within 3 seconds, shown in Fig. 10.




Fig. 10 Video envelope rising when operation mode is switch from review to play mode.

If it does not rise within 3 seconds, adjust as follows :

1. Make sure there is no gap between supply roller lower flange and tape. There is no adjustment for this.
2. Change operation mode from the review to the play mode again and make sure entrance side of envelope rises within 3 seconds.
3. If the envelope rises up then replace either the lower cylinder or base pole "L", then adjust again.

6. Envelope Check

1. Make recordings on E-120 and E-180 tapes, and make sure the playback output envelope meets the specification shown in Fig. 11
2. In playback mode using the same video deck as used for the recording, (with a E-120) the video envelope should meet the specification shown in Fig. 11. In mode, (A) should be same as (B). If the difference is excessive then the upper cylinder should be replaced.




Fig. 11 Envelope output and output level difference

7. Tape Wrinkle Check

1. Run the E-180 tape in the playback, FPS, review and the pause mode and then observe tape wrinkle at each guide.
2. If excessive tape wrinkle is observed at the mode shown below, perform the associated adjustment shown below.

a. Playback mode

Tape wrinkle at the S, T-guide roller section : Line adjustment. (S, T Guide Rollers Adjustment)
Tape wrinkle at tape guide flange : A/C head assen adjustment.

b. Review mode

Tape wrinkle at tape guide : Review arm guide lc adjustment.

3-4. REEL TORQUE

3-4-1. General Features.

1. The rotation of the capstan motor operates the a clutch through the belt capstan motor which is directly connected to the assembly clutch.
2. Brake operation and shift operation in FF/REW one slide way.
3. Transportation of accurate driving force by gear type (clutch ass'y).
4. Auto Torque is converted by CAM system automatically.

MODE	TORQUE μcm	GAUGE
PH/REC	(0) - 130	Cassette Torquem
RPS	140 - 200	Cassette Torquem
FF/REW	Above 1000g/cm	Torque Gauge

Note :
If the Spec is out of above, replace the clutch ass'y check it.

3-4-2. Location of Tension Pole and Back Tension Adjustment

1. Remove the housing ass'y and set the deck to play mode.
2. Adjust the cam tension to set at 0.5 ± 0.2 from the center of supply roller.
3. The back tension meter should be used for adjustment of back tension.
Check back tension, should be $42 \pm 10 \text{ g.cm}$.
If not, check while adjusting cam tension.

Counter-Clock wise : Torque UP
Clock wise : Torque DOWN




Fig. 12 Tension Pole and Back Tension Adjustment

3-4-3. Reel Torque Adjustment

1. Reel torque adjustment

a. Review mode

Excessive torque may damage the tape, however poor torque may not wind the tape.

b. REC/PLAY BACK (Take -Up) Mode

Weak torque can not wind the tape to the end, however excessive torque may make the tape expand.

BACK TENSION METER




Fig. 13 Back Tension Tape Torque Cassette

c. Inspection

Rewind the torque cassette which is recorded in SP mode to the end and measure the torque shown below.

Rewind Torque : 140 - 200 g.cm

Record/Play Back Torque : 60 - 130 g.cm

2. Reel Torque Check

- First, record a TV broadcast program on the entire torque cassette tape (KT-300NR) in the SP mode.
- Load the torque cassette in the VCR and fast forward the tape before proceeding with measurement.
- Set the VCR to the REVIEW mode and feed the tape for about 15 sec., and then make sure the take-up torque of 140 - 190 g.cm is obtained while observing the left torque meter.
- After completion of step 3, set the VCR to the PLAY mode and feed the tape for about 30 sec. Read the right torque meter and check whether the torque of 60-130 g.cm is obtained.
- When the review torque and playback torque are out of limit, replace the clutch assembly.
- When the clutch assembly is replaced, perform the reel torque check.

3. Precautions for Usage of Torque Cassette (KT-300NR)

- Before loading a torque cassette in a VCR, always remove tape slack. The tape slack can be removed by rotating the reel to its take-up direction. (The tape tends to slack when there is no reel brake actions).
- When the torque cassette is loaded, confirm the following:
 1. Make sure the tape does not ride up or over the tape guide cap. If it does, do not eject the tape but bring the tape to its correct position, taking care not to damage the tape.
 2. Make sure the tape has no slack, if it has slack, operate the VCR in FF or REW mode and then stop the tape. Then make sure the tape has no slack.
 3. After above confirmation, proceed to the reel torque adjustments and confirmation.
- Cautions for removal of torque cassette.
 1. When removing the torque cassette from the VCR, set the VCR to the STOP mode and wait for several seconds. Then, make sure the tape has no slack. Push the EJECT button to remove the cassette.
 2. When removing the torque cassette from the VCR, also make sure the tape has no slack inside the cassette lid before pulling the cassette from the VCR. If the tape has no slack inside the lid, carefully bring the tape in place and then pull the cassette.
- If the previous precautions 1, 2 and 3 are not performed properly, the tape may be damaged and correct measurements can not be performed.
- Do not use worn out or damaged tape, if they are used they may damage video heads on the cylinder. In such a case, always replace the tape with a new one.

4-1-2. Alignment tape contents


Tape	Video signal	Audio signal	Applications
SR2-2 (SP)	Colour bars	1 KHz	• Video signal playback circuit checks and adjustments. • Audio signal playback circuit checks and adjustments.
SR1-2 (SP)	Monochrome	6 KHz	• Interchangeability checks and adjustments • SERVO circuit check and adjustments • Audio head Azimuth adjustments

4-1-3. Check and adjustment steps

The check and adjustment steps are provided in the following in the form of charts. For clarity, the nomenclature used in the charts is outlined below.

No.	Checks and adjustments are numbered in the recommended sequence in which they are to be performed.
Item	Name assigned to the particular check and adjustment steps.
Check Point	Location to which measuring instrument (oscilloscope unless otherwise noted) is to be connected
Adjustment Parts	Variable component (resistor capacitor, etc.) to be adjusted in this step.
Signal	Input signal required to perform adjustment.
Mode	Equipment operating mode at time of check of adjustment.
100% White	100% White signal as video input.
Color bar	Colour bar signal as video input
1KHz	Supply a 1KHz sine wave as audio input signal.
STOP	Power on and machine in stop mode.
REC	Recording mode.
PH	Playback mode.
SR2-2	Playback SR2-2 alignment tape
SR1-2	Playback SR1-2 alignment tape
STILL	Playback then pause
Description and Waveform	This column provides an explanation of the step, notes, adjustment values and waveform diagram
MAIN	Main PCB (VIDEO, TUNER, SERVO, AUDIO, SYSTEM CONTROL)
P.A	PRE-AMP PCB
F/T	Function/Timer PCB

-2. SERVO SECTION in Main. PCB






Fig. 8 CCD IN Level Adjustment

1. Connect channel-1 scope probe (0.1V/div) to IC3201 Pin 10.
2. Load the instrument with an alignment tape and play back the color bar signal. (Alignment Tape SR2-2)
3. Adjust the CCD Level Control (VR3203) for 0.5Vp-p.

4-3-2. FM Carrier & Deviation Adjustment

Equipment : Tracking Scope
Test Point : TP3204
Adjust : VR3201 (Deviation)
VR3202 (FM Carrier)




Fig. 9 FM Carrier & Deviation Adjustment

This adjustment sets the frequency of the FM Carrier and Deviation. If deviation is less than 1MHz, the video output level becomes low. When the deviation is more than 1MHz, the output level becomes high and there will be the overmodulation. So the screen has white/dark trigger and the S/N ratio is not good.

1. Apply 100% white signal to the video input jack on the rear panel.
2. Rotate the input selected S/W to AUX.
3. Connect tracking scope to TP3204.
4. Load blank tape and make a recording.
5. Adjust the FM carrier control (VR3202) so that the frequency is 3.8MHz $\pm$ 0.1 MHz.

6. Adjust the deviation control (VR3201) so that the frequency is 4.8MHz $\pm$ 0.1MHz for the 1MHz deviation (See Fig.9)

4-4. TUNER/DEMODULATOR SECTION in Main .PCB



Fig. 10 Tuner/Demodulator Section in Main .PCB Component Side.

4-4-1. TRAP Adjustment (VX Model)




Fig. 11 Composition for TRAP Adjustment

Equipment : Sweep Generator
Test Point : Q401 Collector (IF OUT)
Adjust : FL401, FL402 (TRAP)

1. Place the instrument in E-E mode.
2. Remove connector CN101 and connect DC bias supply of 12V to the pin B + Tuner on the Main PCB.
3. Connect the sweep generator output to tuner TP within the tuner unit. (Fig. 11)
4. Connect input of monitor scope to the collector of Q401.
5. Adjust the trap (FL 401, 402) in the tuner unit shown in Fig. 12.




Fig. 12 TRAP Adjustment

4-4-2. VIF Adjustment




Fig. 13 Composition for VIF Adjustment

Equipment : Sweep Generator, Monitorscope
Test Point : C422 (Video output)
Adjust : FL 404 (VIF-DET TANK)

This adjustment makes the sync detector reference signal tuning circuit of the picture-IF circuit resonates with 38.9MHz (39.5 MHz).

1. Place the instrument in the E-E mode.
2. Remove connector CN101 and connect DC bias supply of 9V, 12V to the pin B +, pin 9 of IC401 on the Main PCB.
3. Connect sweep generator output to tuner TP within the tuner unit. (Fig. 13)
4. Connect monitor scope input to C422.
5. Connect 100 ohm damping resistor between the Pin 12 and pin 13 of IC401.
6. Adjust the core (FL403) in the tuner section shown in Fig. 14
7. Remove 100 ohm damping resistor.
8. Adjust the VIF control (FL404) for maximum. (Fig.15)




Fig. 14 Illustration for balance between VIF and colour signal (Refer to table 1)




Fig. 15 VIF Maximum Detection (Refer to table 1)

4-4-3. AFT Adjustment

Equipment : Sweep Generator, Monitorscope
Test Point : TP401 (AFT Output)
Adjust : FL409 (AFT-BAL)

1. After adjustment of VIF, connect monitorscope input to TP401.
2. Adjust the AFT-BAL (FL409) shown in Fig. 16.




Fig. 16 AFT Adjustment (Refer to table 1)


	(MHz)			
Application Model	A	B	C	D
VX Model	33.4	34.47	38.9	40.4
VI Model	33.5	35.07	39.5	41.5

* Table 1 : Adjusting Frequency


5. TIMING CHART/TROUBLESHOOTING GUIDE

5-1. TIMING CHART


5-1-1. PLAY/UNLOAD/PLAY




5-1-2. EJECT/UNLOAD/EJECT



5-1-3. STOP/REW



5-1-4. PLAY/STOP/PLAY



4-4-4. RF AGC Adjustment

Equipment : TV Channel Signal Generator
Oscilloscope or DC Voltmeter
Test Point : TP402 (Tuner RF AGC Input)
Adjust : VR401 (RF AGC Control)

This adjustment determines the point where the AGC is activated.

1. Apply a PAL colour bar signal to the video input terminal of the TV channel signal generator. (Fig. 17)
2. Set channel selector to A.
3. Apply the output of the generator to the RF IN terminal on the rear panel. Using the attenuator, adjust the point signal level for 70dBu measured at the RF IN Terminator. (Fig. 17)
4. Connect channel-1 scope probe (1V/div) to TP402.
5. Turn the VCR power on and select TV mode with input select key on the front panel.
6. Set the channel on the front panel to CH2 (CI121).
7. Adjust the RF AGC control (VR401) for B. (Refer to table 2)
8. Adjust the input level of the RF IN terminal for 60dBu, check the condition of screen. If the display is noisy adjust VR401 so that the noise disappears.
9. Adjust the input level of the RF IN terminal for 100dBu, then check the condition of screen. If the picture is unstable adjust VR401 until the instability is removed.




Fig. 17 RF AGC Adjustment

Application Model	A (CH, Frequency)	B (Voltage)
VX Model	2CH (48.25MHz)	5.0 +/- 0.1V
VI Model	21CH (471.25MHz)	5.2 +/- 0.1V

* Table 2

4-5. AUDIO SECTION In Main. PCB




Fig. 18 Audio Section in Main Component Side

4-5-1. Audio Bias Level Adjustment

Equipment : AC Millivoltmeter
Test Point : TP1, TP2 (in A/C Head)
Adjust : VR501 (REC Bias Level ADJ)

When the audio record bias is too low, high frequencies are increased resulting in distortion.
When the level is too high, high frequencies are attenuated.

1. Load blank tape and place in the SP record mode with no signal.
2. Connect the A/C Voltmeter to TP1, TP2 in A/C head.
3. Adjust the audio bias level control (VR501) for 2.4 mVrms.

4-6. LP SKEW SECTION




Fig. 19 LP SKEW Section Component Side

4-6-1. LP SKEW Adjustment

Equipment : Oscilloscope
Test Point : TP 202 (SW 25Hz) Main PCB
TPA01 (Jumping Pulse) LP SKEW PCB
TP 3202 (Video Out) Main PCB
Adjust : VRA01 (SKEW Video Level) LP SKEW PCB
VRA02 (Jumping Pulse) LP SKEW PCB

1. Load a blank tape and record color bar signal in LP mode then playback it.
2. Connect CH3 scope probe to TP202, CH2 scope probe to TPA01, CH1 scope probe to TP3202.
3. Trigger the scope on CH3. (1V/div, 50us/div)
4. Set the scope to (+) slope and adjust VRA01 in still mode to equalize the levels.
5. Set the scope to (+) slope and adjust VRA02 so that Jumping pulse is high or low in still mode and is 25Hz in X2 play mode.
6. Confirm the screen shaking is minimized in still and X2 play modes.
Check skew compensation condition in FPS and RPS.






Fig.20 LP SKEW Adjustment

5-1-9. PAUSE/REC/PAUSE




5-2. TROUBLESHOOTING GUIDE


5-2-1.




5-2-2.




5-1-5. PLAY/FPS/PLAY




5-1-7. PLAY/STILL



5-1-6. PLAY/RPS/PLAY




5-1-8. STOP/REC/STOP




5-9

5-2-7.




5-2-8.




5-10


5-2-9.




5-2-10.




5-2-3.




5-2-4.




5-2-5.




5-2-6.




5-2-11.




5-2-12.




5-2-13.



5-2-14.




5-2-15.




5-13

5-2-16.




5-2-17.




5-14

5-2-18.




5-2-19.



5-15

5-2-20.



6. REPLACEMENT PARTS LIST

1. Parts Replacement

Many electrical and mechanical parts in video cassette recorder (player) have special safety-related characteristics. These are after not evident from visual inspection nor the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this manual; electrical components having such features are identified by Δ in the replacement parts lists and schematic diagrams.

The use of a substitute replacement part which does not have the same safety characteristics as the factory recommended replacement parts shown in this service manual may create shock, fire or other hazard.

2. Unless otherwise specified :

- 1) All resistors are in ohms (Ω)
 - K = 1,000
 - M = 1,000K

• RD : 1/8W, $\pm 1\%$ Carbon

• RM : 1/4W, $\pm 1\%$ Metal-film

- 2) All capacitors are in $\pm 10\%$, MF = μF ,

• CC : PP = μF , Ceramic, Temp

• CK : PK = μF , Ceramic, MK

• CS : Tantalum

• CQ : Polyester

• CE : Electrolytic

- 3) All coils are in microhenries (μH), M = 1,000 μH .

3. ASS'Y = Assembly.

4. P. W. B = Printed Wiring Board.

5. Δ Mark : Safety related parts.

6. How to order replacement parts

To have your order filed promptly and correctly, please furnish the following informations.

- 1) Model Number
- 2) Location Number
- 3) Part Number
- 4) Description & Specification

7. P. W. B Assembly is not Replacement Item.

6-1

6-1. MECHANICAL PARTS LIST

LOCAL NO	PART-NUMBER	DESCRIPTION: SPECIFICATION	REMARK	LOCAL NO	PART-NUMBER	DESCRIPTION: SPECIFICATION	REMARK
INSTRUMENT ASSEMBLY							
1	69000-193-009	ASSY-PANEL FRONT : VX-1561		8223	65254-626-210	MAIN BRAKE "L" ASSY : X-1	
1-1	69000-183-068	ASSY-PANEL FRONT : VX-VI-1560		8224	65254-626-310	MAIN BRAKE "R" ASSY : X-1	
2	67642-603-806	DOOR HOUSING : VX-1561		8225	66674-640-710	S/P SUB "R" : SUPB(BLK)	
2-1	67642-605-510	DOOR HOUSING : VX-VI-1560		8226	66674-640-810	S/P SUB "L" : SUS 304 WPB	
50	67642-504-520	DOOR FRONT : VX-1561		8227	66674-642-710	S/P MAIN SLIDE: SUPB(YEL)	
50-1	67642-105-410	DOOR FRONT : VX-VI-1560		8230	65252-600-910	MAIN BRAKE SLIDE ASSY: PBT+SUS	
122	69052-600-966	REGULATOR ASSY : VX-1250/SEC		8231	65253-609-210	LEVER SHIFT: POM	
130	66020-602-310	FRAME		8232	65294-602-310	TENSION CONTROL LEVER: POM	
131	66462-605-510	CONNECTOR-BOARD: NIPS 54MB		8234	66053-604-410	CLUTCH ASSY: (X-1)	
132	66612-604-710	BOTTOM COVER : SPG TO.5		8241	66614-625-010	HEAD BRUSH ASSY: SECC TI.0+CARBON TIP	
133	66074-600-110	LEG : CE M40-70 860-30 (BLK)		8243	63054-309-110	SUMI-CARD: P1.25 9P 180u/m	
137	69057-603-204	ASSY MAIN : XI PAL VX-1560/1561		8246	69000-290-240	ASSY-REEL PCB(R): DX1-NR2	
	69057-603-205	ASSY MAIN : XI PAL VI-1560(WITH OSD)		8247	64769-052-236	MOTOR D.D CAPSTAN: F20K889(X-1)	
143	66614-714-310	BRKT-GUIDE TOP S : SPG TI.0		8248	65254-626-020	D.D BRAKE ASSY: PBT+FELT	
163	66002-603-510	TOP CABINET: NISH TO.85 BLK(VX-1561)		8249	65274-603-210	CAPSTAN BELT: CY65(X-1)	
	66002-603-530	TOP CABINET: NISH TO.85 BLK(VX-VI-1560)		8250	66674-638-010	D.D CAPSTAN S/P: SUS 304(X-1)	
190	67158-240-121	SCREW BH: 2-4X12 FE FZY		8257	66674-646-210	GROUND PLATE BOTTOM: SUS 430 TO.3	
193	67158-240-163	SCREW-TAP BH: 2-4X16 FE FZB		8258	63579-101-027	SU-RECORD: SPPB-S-061	
200	DX1-PR4	FULL DECK ASSY: X-1		8259	66604-633-710	STOPPER P/I: POM	
205	69071-601-201	ASSY F/TIMER : XI PAL VX-1561		907	67004-100-710	SCREW-PH: M3X4 FE FZY	
205-1	69071-603-208	ASSY F/TIMER : XI PAL VI-1560		920	67128-520-203	SCREW-TAPITE PH: M2.6X6 FE FZY	
	69071-601-203	ASSY F/TIMER : XI PAL VX-1560		922	67108-526-243	SCREW-TAP PH: 2S-3X8 FE FZY	
454	69012-601-201	ASSY PRE AMP : XI PAL 4H'D		956	67304-103-410	WASHER-PLAIN: 3.2X6X0.5 POLYSLIDER	
				957	67334-600-310	WASHER SLIT: P12.5XPI5XTO.5	
				961	67304-602-610	WASHER SLIT: P13.6XPI12XTO.5 LUMIRROR(RED)	
				CN6204	63053-804-128	LEAD CONNECTOR ASSY: 826 51004-51004 4P	
				Q6202	62309-110-244	PHOTO INTERRUPTER: NJL5165K	
TRANSPORT MECHANISM ASSEMBLY							
T202	65224-606-220	CAP(MO.8 GUIDE): BURACON M90-44		H500	66122-700-630	F/L HOUSING ASSY : HF-X	
T203	69000-290-220	ASSY LED(R): DX1-NR2		H501	66151-602-210	UPPER CHASSIS: SECC 20/20 T=1.0**	
T206	69000-280-244	G/R & P/R ASSY "R" : X-1		H502	66461-600-120	GUIDE CASSETTE: ABS(GP-2200)BLK	
T207	69000-280-242	G/R & P/R ASSY "L" : X-1		H503	69000-470-610	SIDE CHASSIS(L) ASSY: ABS+POM	
T209	65292-600-620	LOADING UNIT ASSY: POM+SUS+SECC		H504	69000-470-690	SIDE CHASSIS "R" ASSY: ABS+POM+SECC	
T209-1	64769-052-140	MOTOR-LOADING: RF-370C-1537Q		H552	69000-470-620	ASSY CASS HOLDER: SECC+POM+SUS	
T209-2	63579-101-026	SU-PROGRAM: SZ2-S-052(X-1)		H553	69000-470-660	PUB SENSOR ASSY: PUB+TR+WIRE	
T209-3	65204-613-310	GEAR WORK: PBT(BURAMEX #2002)		H556	69000-470-650	ASSY-SIDE ARM: SUM+POM+BURCON	
T213	65203-604-910	WORM GEAR WHEEL: POM(X-1)		H561	65253-608-510	MASK CAM LEVER: POM(M90-44)	
T214	65203-605-010	E/T DRIVE GEAR: PBT(X-1)		H562	65204-613-510	LIGHT SHUTTER: POM(M90-44)	
T215	65241-600-010	MASTER CAM GEAR: POM(X-1)		H563	66674-639-820	S/P LIGHT SHUTTER: SUS 304 WPB	
T216	66613-610-710	E/J DRIVE BRKT: SECC TI.2		H565	66674-639-310	S/P ARM TORSION	
T217	66674-639-210	S/P EJECT DRIVE: SUPB		H573	65203-605-310	JOINT GEAR: POM(WHT)	
T219	65253-611-610	PINCH ROLLER LEVER ASSY		H574	65253-605-310	EJECT SLIDE: SECC 20/20 T=1.6	
T220	65263-601-030	BRAKE LEVER CAM ASSY: SECC 20/20+SUM		C6202	61407-117-104	C-CERAMIC AXIAL: CAX Y TAPG 16V 0.01-M	
T221	65234-602-610	REEL DISK "L" ASSY: POM+SUS		C6203	61407-117-104	C-CERAMIC AXIAL: CAX Y TAPG 16V 0.01-M	
T222	65234-602-620	REEL DISK "R" ASSY: POM+PO CYSETER		Q6203	62309-110-510	PHOTO TR: RPM-20DB	
T228	65254-626-510	BRAKE SUB "R" ASSY: X-1		Q6204	62309-110-510	PHOTO TR: RPM-20DB	
T229	66603-612-810	BRAKE SUB "L" : POM					
T233	66054-609-410	IDLER SUB ASSY: (X-1)					
T235	65253-609-010	TENSION ARM ASSY: SECC+POM+SUS					
T236	65274-603-110	TENSION BAND ASSY: POM+FELT+LUMIRROR					
T237	66674-640-510	TENSION SPRING: SUS304-WPB					
T238	65263-600-810	REVIEW ARM ASSY: SECC 20/20+SUS					
T239	66674-639-020	S/P REVIEW ARM: SUS304-WPB P10.55					
T240	67224-602-011	NYLON MUT: M3 X 4.5 NYLON 66 + SUR					
T242	69000-290-230	ASSY-PCB JOINT(R): DX1-NR2					
T244	65253-609-310	REC LEVER S/W: POM					
T245	66674-641-010	S/P REC S/W: SUS304 WPB					
T252	66674-640-920	SPRING TORSION A/C: SUPB (W1)					
T253	67224-602-011	NYLON MUT: M3 X 4.5 NYLON 66 + SUR					
T254	67224-602-210	CAM ADJUST: ALLOY 5					
T255	69000-290-260	ASSY-A/C HEAD(R): DX1-NR2					
T256	64079-700-454	HEAD MAGNETIC F/E: VTR-1XZPS11-059(X-1)					
T300	69019-123-050	CYLINDER ASSY: CX104P					
T301	69000-390-013	ASSY-UPPER CYLINDER: CX104P					
T302	63005-701-075	PUB-UPPER CYLINDER : 94V0 47x47X1.0T					
T303	69000-390-021	ASSY-LOWER CYLINDER: CX104					
T304	67223-600-110	HOLDER TR ASSY: ZDC+SUS301 CSP TO.2					
T305	69000-390-060	SEMI ASSY-MOTOR(U): CX1					
T306	66121-601-210	CYLINDER-BASE: ADC 12(X-1)					
906	67008-130-061	SCREW-PH: M3X6 FE FZY					
907	67004-100-710	SCREW-PH: M3X4 FE FZY					
909	67008-126-081	SCREW-PH: M2.6X8 FE FZY					
910	67008-126-041	SCREW-BH: M2.6X5 FE FZY					
912	67008-126-236	SCREW-PH: M2.3X6 FE FZY					
913	67008-123-101	SCREW-PH: M2.3X10 FE FZY					
916	67004-126-086	SCREW-BH: M2.6X8 US2N/70391398					
917	67004-100-310	SCREW-PH: M3X8 FE FZY WL					
922	67108-526-243	SCREW-TAP PH: 2S-3X8 FE FZY					
956	67304-103-410	WASHER-PLAIN: 3.2X6X0.5 POLYSLIDER					
957	67334-600-310	WASHER SLIT: P12.5XPI5XTO.5					
961	67304-602-610	WASHER SLIT: P13.6XPI12XTO.5 LUMIRROR					
CN202	63053-916-297	LEAD CON ASSY: 1429 #26 F-46 IL-N-6P-SA					
BOTTOM SIDE MECHANISM ASSEMBLY							
B204	65264-606-510	LOADING GEAR "L" ASSY : X-1					
B205	65264-606-610	LOADING GEAR "R" ASSY : X-1					
B208	65263-601-110	SECTOR GEAR ASSY: SECC+SUS					

6-2. ELECTRICAL REPLACEMENT PARTS LIST

LOCA. NO	PART-NUMBER	DESCRIPTION: SPECIFICATION	REMARK	LOCA. NO	PART-NUMBER	DESCRIPTION: SPECIFICATION	REMARK
69098-600-966 REGULATOR ASSY: VY-1260/SEG				ASSY F/TIMER			
BD101	63053-811-221	POWER CORD ASSY: RLC-2F CP-2		69071-601-203	ASSY F/TIMER: X1 PAL VY-1560		
BD102	62169-403-562	DIODE-STACK: RBV402		69071-601-201	ASSY F/TIMER: X1 PAL VY-1561		
C101	61409-601-320	C-CERAMIC: ECK-BMS 472ME		69071-603-208	ASSY F/TIMER: X1 PAL VY-1560		
C102	61639-906-332	C-ELEC: LC-1831-3300-35-M		F/TIMER COMMON PARTS			
C103	61637-205-470	C-ELEC: CEAP 25V 47M SA(6X11)		C701	61607-421-130	C-ELECTROLYTIC: LC-0511-47-16-M TAP6	
C104	61639-906-332	C-ELEC: LC-1831-3300-35-M		C702	61617-404-220	C-ELEC: CEAP 16V 22M RSS(5X7)	
C105	61637-206-100	C-ELEC: CEAP 35V 10M SA(5X11)		C703	61407-117-104	C-CERAMIC: AXIAL: CAX Y TAP6 16V 0.01-M	
C106	61639-904-472	C-ELEC: LC-1628-4700-16-M		C705	61617-404-101	C-ELEC: CEAP 16V 100M RSS(8X9)	
C107	61607-421-130	C-ELECTROLYTIC: LC-0511-47-16-M TAP6		C706	61407-117-104	C-CERAMIC: AXIAL: CAX Y TAP6 16V 0.01-M	
C108	61637-511-470	C-ELEC: CEAP 100V 47M SG(10X12.5)		C707	61407-105-270	C-CERAMIC: TEMP: CC45 CH TAP6 50V 27-J	
C109	61607-404-473	C-ELECTROLYTIC: CE04M TAP6 100V 47M		C708	61407-105-270	C-CERAMIC: TEMP: CC45 CH TAP6 50V 27-J	
C110	61417-105-210	C-CERAMIC: HK: CK45F TAP6 50V 104-Z		CN701	63054-611-030	FLAT-CABLE: 2760 #26 2.0C-11P-30a/e	
CN100	63053-507-990	LEAD CONNECTOR ASSY: 1007 #26 320 RED Q10		CN702	63348-125-200	CONNECTOR-HOUSING: 5533-20APB	
D101	62169-406-482	DIODE: 1N4148 SAMSUNG		CN703	63348-125-200	CONNECTOR-HOUSING: 5533-20APB	
D102	62169-406-482	DIODE: 1N4148 SAMSUNG		D701	62169-406-482	DIODE: 1N4148 SAMSUNG	
D103	62169-201-060	DIODE: 1N4002 TAP6		D702	62169-406-482	DIODE: 1N4148 SAMSUNG	
D104	62169-201-060	DIODE: 1N4002 TAP6		D703	62169-406-482	DIODE: 1N4148 SAMSUNG	
F101	64709-084-841	FUSE: T315mA 250V T19195 5X20MM WIC EUR		D704	62169-406-482	DIODE: 1N4148 SAMSUNG	
F102	64709-084-842	FUSE: T2.0A 250V T19195 5X20MM WIC EUR		D705	62169-406-482	DIODE: 1N4148 SAMSUNG	
F103	64709-084-810	FUSE: T1.6A 250V T19195 5X20MM WIC EUR		D706	62169-406-482	DIODE: 1N4148 SAMSUNG	
IC101	62109-201-282	IC: MC7812		D707	62169-406-482	DIODE: 1N4148 SAMSUNG	
LF101	62429-014-115	LINE-FILTER: HL38		D708	62169-406-482	DIODE: 1N4148 SAMSUNG	
PT101	62869-190-132	POWER-TRANS: E1 6SX24 220/240V 50HZ		D709	62169-406-482	DIODE: 1N4148 SAMSUNG	
Q101	62149-401-308	TRANSISTOR: 2SD 1944		D710	62169-406-482	DIODE: 1N4148 SAMSUNG	
Q102	62149-401-308	TRANSISTOR: 2SD 1944		D711	62169-406-482	DIODE: 1N4148 SAMSUNG	
Q103	62137-103-380	TRANSISTOR: KSA 733-Y TAP6		D712	62169-406-482	DIODE: 1N4148 SAMSUNG	
R101	61049-427-621	R-METAL OXIDE: RS 1P 620-J TAP6		D713	62169-406-482	DIODE: 1N4148 SAMSUNG	
R102	61048-327-271	R-METAL FILM: RS 1/2P 270-J TAP6		D714	62169-406-482	DIODE: 1N4148 SAMSUNG	
R103	61048-324-122	R-METAL FILM: RM 1/2P 1.2K-J		D719	62169-406-482	DIODE: 1N4148 SAMSUNG	
R104	61048-277-102	R-METAL FILM: RM 1/4T TAP6 1K-J		D720	62169-406-482	DIODE: 1N4148 SAMSUNG	
ZD101	62169-403-302	DIODE-ZENER: MTZ 15A TAP6		D721	62169-423-092	DIODE-ZENER: MTZ 6.8B	
ZD102	62169-403-789	DIODE-ZENER: MTZ 5.6C TAP6		D7701	62319-013-110	DIGITRON: 14-BT-16GX	
ZD103	62169-403-829	DIODE-ZENER: MTZ 30D		IC701	62119-110-948	IC: UPD759216ACW-B11	
REMOCON ASSY				IC702	62119-101-338	IC: CAT93C46P	
69099-613-120 REMOCON ASSY: VY-1561				IC703	62119-103-676	IC: MM1280-Q	
CT01	67643-508-010	DOOR-BATTERY: VY-1561		Q701	62139-302-741	TRANSISTOR: KSC 945-Y	
CT02	61617-408-229	C-ELEC: CEAP 50V 2.2M RSS(4X7)		Q702	62139-302-741	TRANSISTOR: KSC 945-Y	
CT03	61607-421-130	C-ELECTROLYTIC: LC-0511-47-16-M TAP6		R701	61048-277-101	R-METAL FILM: RM 1/4T 100-J	
CT04	61417-109-210	C-CERAMIC: HK: CK45F TAP6 50V 104-Z		R702	61048-277-101	R-METAL FILM: RM 1/4T 100-J	
CT05	61417-109-210	C-CERAMIC: HK: CK45F TAP6 50V 104-Z		R703	61048-177-103	R-METAL FILM: RM 1/8TS 10K-J	
CT06	61407-105-850	C-CERAMIC: TEMP: CC45 CH TAP6 50V 8-B		R704	61048-177-104	R-METAL FILM: RM 1/8TS 100K-J	
CT07	61417-109-210	C-CERAMIC: HK: CK45F TAP6 50V 104-Z		R705	61048-177-103	R-METAL FILM: RM 1/8TS 10K-J	
D702	62169-406-482	DIODE: 1N4148 SAMSUNG		R706	61048-177-222	R-METAL FILM: RM 1/8TS 10K-J	
D704	62169-406-482	DIODE: 1N4148 SAMSUNG		R707	61048-177-222	R-METAL FILM: RM 1/8TS 2.2K-J	
ICT01	62119-103-723	IC: LC5864H-1177		R708	61048-177-221	R-METAL FILM: RM 1/8TS 2.2K-J	
ICT02	62119-401-385	IC: 74HC08 SMT TYPE		R709	61048-177-223	R-METAL FILM: RM 1/8TS 22K-J	
LCD1	62309-109-060	LCD: C6537 TS(A)		R710	61048-177-154	R-METAL FILM: RM 1/8TS 150K-J	
LT01	62309-112-041	LED-IR: GL538		R715	61048-177-154	R-METAL FILM: RM 1/8TS 150K-J	
Q701	62149-301-431	TRANSISTOR: KSC 100B-Y		R716	61048-177-154	R-METAL FILM: RM 1/8TS 150K-J	
R701	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J		R718	61048-177-102	R-METAL FILM: RM 1/8TS 150K-J	
R702	61048-177-689	R-METAL FILM: RM 1/8TS 6.8-J		R719	61048-177-683	R-METAL FILM: RM 1/8TS 1K-J	
RT03	61048-177-303	R-METAL FILM: RM 1/8TS 30K-J		R720	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
XT01	64539-012-528	CRYSTAL: 38.2294KHZ		R721	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
69099-615-100 REMOCON ASSY: VY-1560				R722	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
69099-615-120 REMOCON ASSY: VY-1560				R723	61048-177-683	R-METAL FILM: RM 1/8TS 68K-J	
CT01	67643-608-910	DOOR-BATTERY REMOCON: VY-1560 ABS 94M8		R724	61048-177-683	R-METAL FILM: RM 1/8TS 68K-J	
CT02	61617-408-229	C-ELEC: CEAP 50V 2.2M RSS(4X7)		R725	61048-177-683	R-METAL FILM: RM 1/8TS 68K-J	
CT03	61607-421-130	C-ELECTROLYTIC: LC-0511-47-16-M TAP6		R726	61048-177-683	R-METAL FILM: RM 1/8TS 68K-J	
CT04	61407-117-101	C-CERAMIC: AXIAL: UPO50F 104Z		R750	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
CT05	61407-117-101	C-CERAMIC: AXIAL: UPO50F 104Z		R751	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
CT06	61407-105-850	C-CERAMIC: TEMP: CC45 CH TAP6 50V 8-B		R752	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
CT07	61407-117-101	C-CERAMIC: AXIAL: UPO50F 104Z		R753	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
D702	62169-406-482	DIODE: 1N4148 (UNIQUE PARTS OF VY-1560)		R754	61048-177-102	R-METAL FILM: RM 1/8TS 1K-J	
D704	62169-406-482	DIODE: 1N4148 SAMSUNG		RM701	64529-312-041	REMOCON-MODULE: SBX1610-82	
ICT01	62119-103-723	IC: LC5864H-1177		SW701	63599-016-070	SW-TACT: EVO-QS2 05K	
ICT02	62119-401-385	IC: 74HC08 SMT TYPE		SW702	63599-016-070	SW-TACT: EVO-QS2 05K	
LCD01	62309-109-030	LCD: CG434-TS		SW703	63599-016-070	SW-TACT: EVO-QS2 05K	
LT01	62309-112-036	LED-IR: CL2		SW704	63599-016-070	SW-TACT: EVO-QS2 05K	
LT02	62309-112-036	LED-IR: CL2		SW705	63599-016-070	SW-TACT: EVO-QS2 05K	
Q701	62149-301-431	TRANSISTOR: KSC 100B-Y		SW706	63599-016-070	SW-TACT: EVO-QS2 05K	
R701	61048-177-101	R-METAL FILM: RM 1/8TS 100-J		SW707	63599-016-070	SW-TACT: EVO-QS2 05K	
R702	61048-177-109	R-METAL FILM: RM 1/8TS 1-J		SW710	63599-016-070	SW-TACT: EVO-QS2 05K	
RT03	61048-177-303	R-METAL FILM: RM 1/8TS 30K-J		SW711	63599-016-070	SW-TACT: EVO-QS2 05K	
XT01	64539-012-528	CRYSTAL: 38.2294KHZ		SW712	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW713	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW714	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW715	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW717	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW716	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW719	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW720	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW721	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW722	63599-016-070	SW-TACT: EVO-QS2 05K	
				SW723	63599-016-070	SW-TACT: EVO-QS2 05K	

LOCA.NO	PART-NUMBER	DESCRIPTION:SPECIFICATION	REMARK	LOCA.NO	PART-NUMBER	DESCRIPTION:SPECIFICATION	REMARK
SW724	63599-016-070	SU-TACT:EVC-CS2 CSK		C221	61507-121-260	C-POLYESTER:CO921M TAPG 50V 104-J	
SW725	63599-016-070	SU-TACT:EVC-CS2 CSK		C222	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)	
SW726	63599-016-070	SU-TACT:EVC-CS2 CSK		C224	61607-421-120	C-ELECTROLYTIC:LC-0511-4.7-50-M TAPG	
SW727	63599-016-070	SU-TACT:EVC-CS2 CSK		C226	61A17-109-040	C-CERAMIC:HK:CK45F TAPG 50V 102-Z	
VR701	61203-107-110	VR ROUND:R:OSK1130/RHD10250 20KΩ		C228	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
X1701	64539-102-044	CERAMIC-RESONATOR:FCR 4.19MC		C233	61507-121-481	C-POLYESTER:CO921M TAPG 50V 153-J	
X1702	64539-021-010	CRYSTAL:P-3(32.768KHZ)		C234	61637-208-010	C-ELEC:CEAP 50V 1M SA(SX11)	
UNIQUE PARTS OF VX-1560				C235	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
D711	62169-406-482	DIODE:1N4148 SAMSUNG		C236	61637-208-010	C-ELEC:CEAP 50V 1M SA(SX11)	
D723	62169-406-482	DIODE:1N4148 SAMSUNG		C237	61407-117-228	C-CERAMIC:AXIAL:CAX SL TAPG 50V 223-Z	
L701	62429-833-101	COIL-PEAKING AXIAL:8AL04ST 101K		C238	61417-109-210	C-CERAMIC:HK:CK45F TAPG 50V 104-Z	
UNIQUE PARTS OF VX-1561				C239	61637-208-339	C-ELEC:CEAP 50V 3.3M SA(SX11)	
C750	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J		C240	61417-109-210	C-CERAMIC:HK:CK45F TAPG 50V 104-Z	
D718	62169-406-482	DIODE:1N4148 SAMSUNG		C241	61617-404-470	C-ELEC:CEAP 16V 47M RSS(6.3X7)	
R711	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C242	61637-504-471	C-ELEC:CEAP 16V 470M SG(10X12.5)	
R712	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C243	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)	
R713	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C244	61507-121-600	C-POLYESTER:CO921M TAPG 100V 563-K	
R717	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C245	61637-504-101	C-ELEC:CEAP 16V 100M SG(6.3X11)	
SW716	63599-016-070	SU-TACT:EVC-CS2 CSK		C246	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J	
UNIQUE PARTS OF VI-1560				C248	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J	
D718	62169-406-482	DIODE:1N4148 SAMSUNG		CN201	63053-209-126	LEAD CONNECTOR ASSY:1429 #26 5295-S1004	
R711	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		CN202	63053-916-298	LEAD CONNECTOR ASSY:1429 #26 5250M/m	
R712	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		CN204	63054-607-250	FLAT-CABLE:2760 #26 2.0C-7P-250M/m	
R713	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		D202	62169-406-482	DIODE:1N4148 SAMSUNG	
R717	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		D205	62169-406-482	DIODE:1N4148 SAMSUNG	
SW716	63599-016-070	SU-TACT:EVC-CS2 CSK		D206	62169-406-482	DIODE:1N4148 SAMSUNG	
69057-603-204		ASSY MAIN : VX-1560/1561		D208	62169-406-482	DIODE:1N4148 SAMSUNG	
69057-603-205		ASSY MAIN : VI-1560		D209	62169-406-482	DIODE:1N4148 SAMSUNG	
POWER PARTS				D210	62169-406-482	DIODE:1N4148 SAMSUNG	
C111	61607-421-130	C-ELECTROLYTIC:LC-0511-47-16-M TAPG		D211	62169-406-482	DIODE:1N4148 SAMSUNG	
C112	61607-421-130	C-ELECTROLYTIC:LC-0511-47-16-M TAPG		D212	62169-201-050	DIODE:1N4001 TAPG	
C114	61607-421-130	C-ELECTROLYTIC:LC-0511-47-16-M TAPG		D213	62169-201-050	DIODE:1N4001 TAPG	
CN101	63053-110-125	LEAD CONNECTOR ASSY:1429 #26 5295-5264		D214	62169-406-482	DIODE:1N4148 SAMSUNG	
D105	62169-406-482	DIODE:1N4148 SAMSUNG		D215	62169-406-482	DIODE:1N4148 SAMSUNG	
D106	62169-201-050	DIODE:1N4001 TAPG		D216	62169-406-482	DIODE:1N4148 SAMSUNG	
D108	62169-201-050	DIODE:1N4001 TAPG		D217	62169-406-482	DIODE:1N4148 SAMSUNG	
D109	62169-201-050	DIODE:1N4001 TAPG		D250	62169-406-482	DIODE:1N4148 SAMSUNG	
D110	62169-201-050	DIODE:1N4001 TAPG		IC201	62119-401-862	IC:HD49748NT	
Q104	62147-401-835	TRANSISTOR:KSA 928A-Y TAPG		IC202	62119-401-872	IC:LM393(N.M)	
Q105	62147-401-835	TRANSISTOR:KSA 928A-Y TAPG		IC203	62119-501-572	IC-LINEAR:LM358S(N.A)	
Q106	62137-701-010	TRANSISTOR:KSR 1001 TAPG		IC204	62119-101-770	IC:TC4094BP/MC14094BCP	
Q107	62137-701-012	TRANSISTOR:KSR 1003 TAPG		IC205	62119-101-770	IC:TC4094BP/MC14094BCP	
Q108	62137-701-022	TRANSISTOR:KSR 2003 TAPG		IC206	62119-401-300	IC:KAB301(N.M)	
R105	61048-177-222	R-METAL FILM:RM 1/8TS 2.2K-J		L201	62429-833-101	COIL-PEAKING AXIAL:8AL04ST 101K	
R106	61048-177-562	R-METAL FILM:RM 1/8TS 5.6K-J		Q205	62137-701-012	TRANSISTOR:KSR 1003 TAPG	
R107	61048-177-562	R-METAL FILM:RM 1/8TS 5.6K-J		Q209	62137-302-740	TRANSISTOR:KSC 945-Y TAPG	
R108	61048-177-681	R-METAL FILM:RM 1/8TS 680-J		Q210	62137-103-380	TRANSISTOR:KSA 733-Y TAPG	
R110	61048-277-821	R-METAL FILM:RM 1/4T 820-J		Q211	62137-103-380	TRANSISTOR:KSA 733-Y TAPG	
SYSTEM CONTROL PARTS				Q212	62137-302-740	TRANSISTOR:KSC 945-Y TAPG	
C603	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J		Q213	62137-701-012	TRANSISTOR:KSR 1003 TAPG	
C604	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J		Q214	62137-701-013	TRANSISTOR:KSR 1004 TAPG	
C605	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J		Q215	62147-401-835	TRANSISTOR:KSA 928A-Y TAPG	
L602	62429-833-101	COIL-PEAKING AXIAL:8AL04ST 101K		Q216	62147-401-830	TRANSISTOR:KSD 261-Y TAPG	
Q601	62137-701-022	TRANSISTOR:KSR 2003 TAPG		R201	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J	
R609	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		R202	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J	
R610	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		R203	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J	
R611	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		R204	61048-177-823	R-METAL FILM:RM 1/8TS 82K-J	
SERVO PARTS				R205	61048-177-472	R-METAL FILM:RM 1/8TS 4.7K-J	
C201	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)		R206	61048-177-563	R-METAL FILM:RM 1/8TS 56K-J	
C202	61507-121-340	C-POLYESTER:CO921M TAPG 100V 102-K		R207	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J	
C203	61637-208-010	C-ELEC:CEAP 50V 1M SA(SX11)		R208	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J	
C204	61507-121-430	C-POLYESTER:CO921M TAPG 100V 472-K		R209	61048-177-122	R-METAL FILM:RM 1/8TS 1.2K-J	
C206	61507-121-550	C-POLYESTER:CO921M TAPG 50V 473-K		R210	61048-177-362	R-METAL FILM:RM 1/8TS 3.6K-J	
C207	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)		R211	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J	
C208	61637-208-010	C-ELEC:CEAP 50V 1M SA(SX11)		R212	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J	
C209	61607-421-120	C-ELECTROLYTIC:LC-0511-4.7-50-M TAPG		R214	61048-177-272	R-METAL FILM:RM 1/8TS 2.7K-J	
C210	61507-121-550	C-POLYESTER:CO921M TAPG 50V 473-K		R217	61048-177-334	R-METAL FILM:RM 1/8TS 330K-J	
C211	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)		R218	61048-177-562	R-METAL FILM:RM 1/8TS 5.6K-J	
C212	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)		R219	61048-177-334	R-METAL FILM:RM 1/8TS 330K-J	
C213	61507-121-340	C-POLYESTER:CO921M TAPG 100V 102-K		R220	61048-177-182	R-METAL FILM:RM 1/8TS 1.8K-J	
C214	61507-121-620	C-POLYESTER:CO921M 100V TAPG 224-K		R221	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J	
C215	61607-421-130	C-ELECTROLYTIC:LC-0511-47-16-M TAPG		R222	61048-177-105	R-METAL FILM:RM 1/8TS 1M-J	
C216	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M		R223	61048-177-683	R-METAL FILM:RM 1/8TS 68K-J	
C217	61417-109-040	C-CERAMIC:HK:CK45F TAPG 50V 102-Z		R224	61048-177-334	R-METAL FILM:RM 1/8TS 330K-J	
C218	61607-421-160	C-ELECTROLYTIC:LC-0511-22-16-M TAPG		R225	61048-177-105	R-METAL FILM:RM 1/8TS 1M-J	
C219	61607-421-160	C-ELECTROLYTIC:LC-0511-22-16-M TAPG		R226	61048-177-393	R-METAL FILM:RM 1/8TS 39K-J	
C220	61407-101-460	C-CERAMIC:TEMP:CC45 SL TAPG 50V 270-J		R227	61048-177-564	R-METAL FILM:RM 1/8TS 560K-J	
				R228	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J	
				R229	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J	
				R230	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J	
				R231	61048-177-473	R-METAL FILM:RM 1/8TS 47K-J	
				R232	61048-177-105	R-METAL FILM:RM 1/8TS 1M-J	
				R233	61048-177-183	R-METAL FILM:RM 1/8TS 18K-J	
				R234	61048-177-154	R-METAL FILM:RM 1/8TS 150K-J	
				R235	61048-177-823	R-METAL FILM:RM 1/8TS 82K-J	
				R236	61048-177-474	R-METAL FILM:RM 1/8TS 470K-J	
				R237	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J	
				R238	61048-177-823	R-METAL FILM:RM 1/8TS 82K-J	
				R239	61048-177-822	R-METAL FILM:RM 1/8TS 8.2K-J	
				R240	61048-177-431	R-METAL FILM:RM 1/8TS 430-J	

LOC. NO.	PART NUMBER	DESCRIPTION SPECIFICATION	REMARK	LOC. NO.	PART NUMBER	DESCRIPTION SPECIFICATION	REMARK
R241	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3401	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R242	61048-177-105	R-METAL FILM;RM 1/8TS 1K-J		C3402	61407-101-360	C-CERAMIC.TEMP;CC45 SL TAPG 50V 100-J	
R243	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		C3403	61637-504-101	C-ELEC;CEAP 16V 100M S6(6.3X11)	
R251	61048-177-104	R-METAL FILM;RM 1/3TS 100K-J		C3404	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R252	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		C3405	61407-105-320	C-CERAMIC.TEMP;CC45 CH TAPG 50V 82-J	
R253	61048-177-272	R-METAL FILM;RM 1/8TS 2.7K-J		C3406	61407-105-360	C-CERAMIC.TEMP;CC45 CH TAPG 50V 43-J	
R254	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		C3407	61507-121-470	C-POLYESTER;CQ921M TAPG 100V 103-K	
R255	61048-177-431	R-METAL FILM;RM 1/8TS 430-J		C3408	61637-208-010	C-ELEC;CEAP 50V 1M SA(SX11)	
R256	61048-177-562	R-METAL FILM;RM 1/8TS 5.6K-J		C3409	61507-121-510	C-POLYESTER;CQ921M TAPG 100V 223-K	
R257	61048-177-101	R-METAL FILM;RM 1/8TS 100-J		C3410	61507-121-570	C-POLYESTER;CQ921M TAPG 100V 683-K	
R258	61048-177-272	R-METAL FILM;RM 1/8TS 2.7K-J		C3411	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R259	61049-427-010	R-METAL OXIDE;RS 1P 1-J		C3412	61507-121-510	C-POLYESTER;CQ921M TAPG 100V 223-K	
R260	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		C3413	61637-208-010	C-ELEC;CEAP 50V 1M SA(SX11)	
R261	61048-177-222	R-METAL FILM;RM 1/8TS 2.2K-J		C3414	61637-208-010	C-ELEC;CEAP 50V 1M SA(SX11)	
R262	61048-177-222	R-METAL FILM;RM 1/8TS 2.2K-J		C3415	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R263	61048-177-472	R-METAL FILM;RM 1/8TS 4.7K-J		C3416	61407-101-360	C-CERAMIC.TEMP;CC45 SL TAPG 50V 100-J	
R264	61048-177-472	R-METAL FILM;RM 1/8TS 4.7K-J		C3417	61507-121-430	C-POLYESTER;CQ921M TAPG 100V 472-K	
R265	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3418	61507-121-550	C-POLYESTER;CQ921M TAPG 50V 473-K	
R266	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3419	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R267	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3420	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG	
R269	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3421	61407-101-360	C-CERAMIC.TEMP;CC45 SL TAPG 50V 100-J	
R270	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3422	61637-208-010	C-ELEC;CEAP 50V 1M SA(SX11)	
R275	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3423	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R276	61048-177-302	R-METAL FILM;RM 1/8TS 3K-J		C3424	61507-121-550	C-POLYESTER;CQ921M TAPG 50V 473-K	
R277	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		C3425	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R278	61048-177-122	R-METAL FILM;RM 1/8TS 1.2K-J		C3427	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R279	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3429	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R280	61048-177-330	R-METAL FILM;RM 1/8TS 33-J		C3430	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG	
R281	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		C3436	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG	
R282	61048-177-272	R-METAL FILM;RM 1/8TS 2.7K-J		C3437	61407-105-320	C-CERAMIC.TEMP;CC45 CH TAPG 50V 82-J	
R283	61048-177-302	R-METAL FILM;RM 1/8TS 3K-J		C3439	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R284	61048-177-473	R-METAL FILM;RM 1/8TS 47K-J		C3502	61617-404-470	C-ELEC;CEAP 16V 47M RSS(6.3X7)	
R285	61048-177-473	R-METAL FILM;RM 1/8TS 47K-J		C3504	61637-206-100	C-ELEC;CEAP 35V 10M SA(SX11)	
R289	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3506	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M	
R291	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3507	61407-101-440	C-CERAMIC.TEMP;CC45 SL TAPG 50V 220-J	
R292	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3508	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG	
R293	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3509	61637-504-471	C-ELEC;CEAP 16V 470M S6(10X12.5)	
R294	61048-177-102	R-METAL FILM;RM 1/8TS 1K-J		C3510	61407-105-320	C-CERAMIC.TEMP;CC45 CH TAPG 50V 82-J	
R295	61048-177-104	R-METAL FILM;RM 1/8TS 100K-J		C3511	61407-105-320	C-CERAMIC.TEMP;CC45 CH TAPG 50V 82-J	
R296	61048-177-823	R-METAL FILM;RM 1/8TS 82K-J		CF3402	64569-006-011	DELAY LINE;MS-31PC-5K	
R297	61048-177-103	R-METAL FILM;RM 1/8TS 10K-J		D3201	62169-406-482	DIODE;1N4148 SAMSUNG	
VR201	61247-101-104	VR-SEMI;EVM-DJA M03 B15 TAPG 100KB		D3202	62169-406-482	DIODE;1N4148 SAMSUNG	
VIDEO PARTS				D3401	62169-406-482	DIODE;1N4148 SAMSUNG	
VIDEO COMMON PARTS				FL3201	64529-431-091	FILTER-LC DIP TYPE;CQ0003	
C3201	61637-204-330	C-ELEC;CEAP 16V 33M SA(SX11)		FL3401	64529-401-200	FILTER-LC;SFB 4141	
C3202	61407-101-160	C-CERAMIC.TEMP;CC45 SL TAPG 50V 15-J		IC3201	62119-103-662	IC;LA7323	
C3203	61407-103-680	C-CERAMIC.TEMP;CC45 PH TAPG 50V 68-J		IC3202	62119-701-063	IC;MSM7401RS	
C3204	61407-101-380	C-CERAMIC.TEMP;CC45 SL TAPG 50V 120-J		IC3401	62119-103-650	IC;LA7331	
C3205	61407-105-680	C-CERAMIC.TEMP;CC45 CH TAPG 50V 200-J		IC3501	62119-401-310	IC;KA8403	
C3206	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		L3201	62427-812-180	COIL-PEAKING;ELO606RA 18uH-J	
C3207	61407-105-250	C-CERAMIC.TEMP;CC45 CH TAPG 50V 39-J		L3202	62427-812-220	COIL-PEAKING;ELO606RA 22uH-J	
C3208	61637-206-100	C-ELEC;CEAP 35V 10M SA(SX11)		L3203	62427-812-101	COIL-PEAKING;ELO606RA 100uH-J	
C3209	61637-208-478	C-ELEC;CEAP 50V 0.47M SA(SX11)		L3204	62427-812-221	COIL-PEAKING;ELO606RA 220uH-J	
C3210	61607-421-160	C-ELECTROLYTIC;LC-0511-22-16-M TAPG		L3205	62429-833-101	COIL-PEAKING AXIAL;BALOAST 101K	
C3211	61607-421-160	C-ELECTROLYTIC;LC-0511-22-16-M TAPG		L3206	62427-812-470	COIL-PEAKING;ELO606RA 47uH-J	
C3212	61637-208-229	C-ELEC;CEAP 50V 2.2M SA(SX11)		L3207	62427-812-151	COIL-PEAKING;ELO606RA 150uH-J	
C3214	61637-504-101	C-ELEC;CEAP 16V 100M S6(6.3X11)		L3208	62427-812-101	COIL-PEAKING;ELO606RA 100uH-J	
C3215	61407-101-160	C-CERAMIC.TEMP;CC45 SL TAPG 50V 15-J		L3209	62427-812-101	COIL-PEAKING;ELO606RA 100uH-J	
C3216	61407-101-510	C-CERAMIC.TEMP;CC45 SL TAPG 50V 470-J		L3401	62429-833-101	COIL-PEAKING AXIAL;BALOAST 101K	
C3217	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		L3402	62427-812-309	COIL-PEAKING;ELO606RA 30uH-J	
C3218	61507-121-570	C-POLYESTER;CQ921M TAPG 100V 683-K		L3403	62427-812-180	COIL-PEAKING;ELO606RA 18uH-J	
C3219	61407-105-280	C-CERAMIC.TEMP;CC45 CH TAPG 50V 56-J		L3404	62427-812-101	COIL-PEAKING;ELO606RA 100uH-J	
C3220	61407-101-360	C-CERAMIC.TEMP;CC45 SL TAPG 50V 100-J		L3405	62427-813-822	COIL-PEAKING;ELO607RA 820uH-J	
C3221	61407-105-330	C-CERAMIC.TEMP;CC45 CH TAPG 50V 33-J		L3406	62427-812-101	COIL-PEAKING;ELO606RA 100uH-J	
C3222	61637-208-478	C-ELEC;CEAP 50V 0.47M SA(SX11)		L3408	62427-812-150	COIL-PEAKING;ELO606RA 15uH-J	
C3223	61607-421-120	C-ELECTROLYTIC;LC-0511-4.7-50-M TAPG		L3409	62427-812-220	COIL-PEAKING;ELO606RA 22uH-J	
C3224	61637-208-478	C-ELEC;CEAP 50V 0.47M SA(SX11)		L3503	62427-812-180	COIL-PEAKING;ELO606RA 18uH-J	
C3225	61407-101-160	C-CERAMIC.TEMP;CC45 SL TAPG 50V 15-J		Q3201	62137-701-011	TRANSISTOR;KSR 1002 TAPG	
C3226	61407-101-360	C-CERAMIC.TEMP;CC45 SL TAPG 50V 100-J		Q3202	62137-701-011	TRANSISTOR;KSR 1002 TAPG	
C3227	61407-101-490	C-CERAMIC.TEMP;CC45 SL TAPG 50V 390-J		Q3203	62147-101-950	TRANSISTOR;KSA 643-Y TAPG	
C3228	61407-105-660	C-CERAMIC.TEMP;CC45 CH TAPG 50V 5-D		Q3204	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
C3229	61407-101-440	C-CERAMIC.TEMP;CC45 SL TAPG 50V 220-J		Q3205	62137-701-023	TRANSISTOR;KSR 2004 TAPG	
C3230	427-101-483	C-CERAMIC.TEMP;CC45 SL TAPG 50V 47-J		Q3206	62137-701-023	TRANSISTOR;KSR 2004 TAPG	
C3231	427-101-200	C-CERAMIC.TEMP;CC45 SL TAPG 50V 22-J		Q3210	62137-103-380	TRANSISTOR;KSA 733-Y TAPG	
C3232	61407-101-170	C-CERAMIC.TEMP;CC45 SL TAPG 50V 150-J		Q3211	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
C3233	61637-504-101	C-ELEC;CEAP 16V 100M S6(6.3X11)		Q3212	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
C3234	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		Q3213	62137-103-380	TRANSISTOR;KSA 733-Y TAPG	
C3235	61507-121-470	C-POLYESTER;CQ921M TAPG 100V 103-K		Q3214	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
C3236	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		Q3215	62137-701-020	TRANSISTOR;KSR 2001 TAPG	
C3237	61637-608-338	C-ELEC;CEAP 50V 0.33M SV(SX9)		Q3216	62137-701-011	TRANSISTOR;KSR 1002 TAPG	
C3238	61607-421-120	C-ELECTROLYTIC;LC-0511-4.7-50-M TAPG		Q3217	62147-101-950	TRANSISTOR;KSA 643-Y TAPG	
C3239	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG		Q3401	62137-103-380	TRANSISTOR;KSA 733-Y TAPG	
C3240	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG		Q3402	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
C3241	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		Q3403	62137-701-013	TRANSISTOR;KSR 1004 TAPG	
C3242	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		Q3404	62137-103-380	TRANSISTOR;KSA 733-Y TAPG	
C3243	61407-117-104	C-CERAMIC.AXIAL;CAX Y TAPG 16V 0.01-M		Q3405	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
C3290	61607-421-130	C-ELECTROLYTIC;LC-0511-47-16-M TAPG		Q3406	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
				Q3407	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
				Q3409	62137-302-740	TRANSISTOR;KSC 945-Y TAPG	
				Q3411	62137-103-380	TRANSISTOR;KSA 733-Y TAPG	


LOC. NO.	PART NUMBER	DESCRIPTION: SPECIFICATION	REMARK	LOC. NO.	PART NUMBER	DESCRIPTION: SPECIFICATION	REMARK
Q3501	62137-702-020	TRANSISTOR:KSC 945-Y TAPG		VX3201	61247-01-472	VR-SEMI:EVN-DJA A03 B03 TAPG 4.7K8	
Q3502	62137-302-740	TRANSISTOR:KSC 945-Y TAPG		VX3202	61247-01-472	VR-SEMI:EVN-DJA A03 B03 TAPG 4.7K8	
Q3503	62137-103-280	TRANSISTOR:KSA 753-Y TAPG		VX3203	61247-01-T02	VR-SEMI:EVN-DJA A03 B13 TAPG 1K8	
R3201	61048-177-203	R-METAL FILM:RM 1/8TS 20K-J		AS401	64539-312-079	X-TAL:4.43 3619MHZ 8PPM TAPG	
R3202	61048-177-472	R-METAL FILM:RM 1/8TS 4.7K-J		ZD3201	62169-403-301	DIODE-ZENER:UZ 3.08 TAPG	
R3203	61048-177-223	R-METAL FILM:RM 1/8TS 22K-J		VIDEO PARTS : UNIQUE PARTS OF VX-1560/1561			
R3204	61048-177-473	R-METAL FILM:RM 1/8TS 4.7K-J		C3432	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3205	61048-177-222	R-METAL FILM:RM 1/8TS 22K-J		C3434	61637-204-330	C-ELEC:CEAP 16V 33M SA(X11)	
R3206	61048-177-181	R-METAL FILM:RM 1/8TS 18K-J		C3435	61637-206-100	C-ELEC:CEAP 35V 10M SA(X11)	
R3207	61048-177-821	R-METAL FILM:RM 1/8TS 820-J		C3436	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3208	61048-177-391	R-METAL FILM:RM 1/8TS 390-J		C3505	61637-504-221	C-ELEC:CEAP 16V 220M SG(8X11.5)	
R3209	61048-177-182	R-METAL FILM:RM 1/8TS 1.8K-J		FL3402	64529-310-010	FILTER-CERAMIC:SFE 4.5M8	
R3210	61048-177-182	R-METAL FILM:RM 1/8TS 1.8K-J		IC3402	62119-103-694	IC:BA702SL	
R3211	61048-177-102	R-METAL FILM:RM 1/8TS 10K-J		L3502	62427-812-821	COIL-PEAKING:EL0606RA 820UH-J	
R3212	61048-177-222	R-METAL FILM:RM 1/8TS 22K-J		Q3413	62137-302-740	TRANSISTOR:KSC 945-Y TAPG	
R3213	61048-177-333	R-METAL FILM:RM 1/8TS 33K-J		Q3414	62137-701-013	TRANSISTOR:KSR 1004 TAPG	
R3214	61048-177-153	R-METAL FILM:RM 1/8TS 15K-J		Q3416	62137-701-013	R-METAL FILM:RM 1/8TS 10K-J	
R3215	61048-177-153	R-METAL FILM:RM 1/8TS 15K-J		R3441	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J	
R3216	61048-177-474	R-METAL FILM:RM 1/8TS 47K-J		R3442	61048-177-102	R-METAL FILM:RM 1/8TS 82K-J	
R3217	61048-177-123	R-METAL FILM:RM 1/8TS 3.6K-J		R3443	61048-177-823	R-METAL FILM:RM 1/8TS 10K-J	
R3218	61048-177-362	R-METAL FILM:RM 1/8TS 36K-J		R3444	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J	
R3219	61048-177-122	R-METAL FILM:RM 1/8TS 35K-J		R3445	61048-177-153	R-METAL FILM:RM 1/8TS 15K-J	
R3221	61048-177-333	R-METAL FILM:RM 1/8TS 33K-J		R3446	61048-177-153	R-METAL FILM:RM 1/8TS 5.6K-J	
R3222	61048-177-301	R-METAL FILM:RM 1/8TS 30K-J		R3447	61048-177-562	R-METAL FILM:RM 1/8TS 10K-J	
R3223	61048-177-681	R-METAL FILM:RM 1/8TS 68K-J		R3448	61048-177-103	R-METAL FILM:RM 1/8TS 150K-J	
R3225	61048-177-682	R-METAL FILM:RM 1/8TS 6.8K-J		R3450	61048-177-154	R-METAL FILM:RM 1/8TS 1K-J	
R3226	61048-177-222	R-METAL FILM:RM 1/8TS 2.2K-J		R3451	61048-177-222	R-METAL FILM:RM 1/8TS 2.2K-J	
R3227	61048-177-475	R-METAL FILM:RM 1/8TS 4.7K-J		R3452	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J	
R3228	61048-177-105	R-METAL FILM:RM 1/8TS 10K-J		R3452	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J	
R3229	61048-177-105	R-METAL FILM:RM 1/8TS 56K-J		R3453	61048-177-223	R-METAL FILM:RM 1/8TS 22K-J	
R3230	61048-177-561	R-METAL FILM:RM 1/8TS 56K-J		R3455	61048-177-222	R-METAL FILM:RM 1/8TS 2.2K-J	
R3231	61048-177-681	R-METAL FILM:RM 1/8TS 6.8K-J		T3401	62429-014-112	COIL-TRAP(1/2FH):7.8K TUNING-COIL	
R3232	61048-177-272	R-METAL FILM:RM 1/8TS 2.7K-J		VIDEO PARTS : UNIQUE PARTS OF VI-1560			
R3233	61048-177-472	R-METAL FILM:RM 1/8TS 4.7K-J		C3505	61637-504-101	C-ELEC:CEAP 16V 100M SG (6.3X11)	
R3235	61048-177-682	R-METAL FILM:RM 1/8TS 6.8K-J		L3502	62427-812-101	COIL-PEAKING:EL0606RA 100UH-J	
R3236	61048-177-102	R-METAL FILM:RM 1/8TS 10K-J		TUNER PARTS : VX-1560/1561			
R3237	61048-177-272	R-METAL FILM:RM 1/8TS 2.7K-J		C3520	64519-903-170	TUNER:ECC-28B5PLE	
R3238	61048-177-102	R-METAL FILM:RM 1/8TS 1.1K-J		C401	62569-002-284	RF-CONVERTER:RMUS23655EA	
R3239	61048-177-112	R-METAL FILM:RM 1/8TS 4.7K-J		C402	63054-401-821	COAXIAL-CABLE ASSY:7/0.16 300V BLK 180AA	
R3240	61048-177-472	R-METAL FILM:RM 1/8TS 1.5K-J		C403	61407-105-320	C-CERAMIC:TEMP:CC45 CH TAPG 50V 82-J	
R3241	61048-177-152	R-METAL FILM:RM 1/8TS 1.5K-J		C404	61407-105-270	C-CERAMIC:TEMP:CC45 CH TAPG 50V 27-J	
R3242	61048-177-272	R-METAL FILM:RM 1/8TS 2.7K-J		C405	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3243	61048-177-272	R-METAL FILM:RM 1/8TS 4.7K-J		C406	61407-105-270	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3244	61048-177-472	R-METAL FILM:RM 1/8TS 56K-J		C407	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3247	61048-177-561	R-METAL FILM:RM 1/8TS 1K-J		C408	61407-105-270	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3248	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C409	61407-105-250	C-ELECTROLYTIC:LC-0511-4.7-50-M TAPG	
R3401	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C410	61607-421-120	C-POLYESTER:CO921M TAPG 100V 222-K	
R3402	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C411	61507-121-390	C-POLYESTER:CO921M TAPG 100V 103-K	
R3403	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J		C412	61507-121-470	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M	
R3404	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J		C413	61607-421-130	C-ELECTROLYTIC:LC-0511-47-16-M TAPG	
R3405	61048-177-152	R-METAL FILM:RM 1/8TS 1.5K-J		C414	61607-421-100	C-ELEC:CEAP 50V 10M SA(X11)	
R3406	61048-177-392	R-METAL FILM:RM 1/8TS 3.9K-J		C415	61637-208-100	C-CERAMIC:AXIAL:CAX SL TAPG 50V 223-J	
R3407	61048-177-822	R-METAL FILM:RM 1/8TS 8.2K-J		C416	61407-117-228	C-CERAMIC:TEMP:CC45 SL TAPG 50V 15-J	
R3408	61048-177-223	R-METAL FILM:RM 1/8TS 22K-J		C417	61407-101-160	C-POLYESTER:CO921M TAPG 100V 104-M	
R3409	61048-177-122	R-METAL FILM:RM 1/8TS 1.2K-J		C418	61507-121-920	C-ELEC:CEAP 50V 0.47M SA(X11)	
R3410	61048-177-223	R-METAL FILM:RM 1/8TS 22K-J		C419	61637-208-478	C-ELEC:CEAP 50V 1M SA(X11)	
R3411	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C420	61637-208-010	C-CERAMIC:TEMP:CC45 SL TAPG 50V 6-D	
R3412	61048-177-153	R-METAL FILM:RM 1/8TS 27K-J		C421	61617-404-100	C-ELEC:CEAP 16V 10M RSS(4X7)	
R3413	61048-177-273	R-METAL FILM:RM 1/8TS 27K-J		C422	62429-832-020	COIL-TRAP:DAISIN 40.4MHZ(6-5.7)	
R3414	61048-177-273	R-METAL FILM:RM 1/8TS 12K-J		FL401	62429-832-010	COIL-TRAP:DAESIN 32.4MHZ(6-7)	
R3415	61048-177-123	R-METAL FILM:RM 1/8TS 1K-J		FL402	62429-832-080	COIL VARIABLE:1.2UH PSF MATCH	
R3416	61048-177-102	R-METAL FILM:RM 1/8TS 330-J		FL403	62719-049-012	TRANS-RESONANT(T1):40MHZ V-DET	
R3417	61048-177-331	R-METAL FILM:RM 1/8TS 1K-J		FL404	64529-421-020	CERAMIC-TRAP:TPS-5.5M8	
R3418	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		FL405	64529-421-021	CERAMIC-TRAP:TPS-5.5M8	
R3419	61048-177-102	R-METAL FILM:RM 1/8TS 580-J		FL406	64529-425-070	FILTER-CERAMIC:CDA 5.5ME21	
R3420	61048-177-681	R-METAL FILM:RM 1/8TS 330-J		FL407	64529-310-012	FILTER-CERAMIC:SFE-5.5M8	
R3421	61048-177-331	R-METAL FILM:RM 1/8TS 1K-J		FL408	62719-049-013	TRANS-AFT(T2):40MHZ AFT-8AL	
R3422	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		FL410	64529-418-041	FILTER-SAW:TSF-1303	
R3423	61048-177-392	R-METAL FILM:RM 1/8TS 3.9K-J		IC401	62119-103-721	IC:LAT545	
R3424	61048-177-152	R-METAL FILM:RM 1/8TS 1.5K-J		L401	62427-812-188	COIL PEAKING:EL0606RA 0.47UH-M	
R3425	61048-177-221	R-METAL FILM:RM 1/8TS 220-J		L402	62427-812-229	COIL-PEAKING:EL0606RA 2.2UH-K	
R3426	61048-177-821	R-METAL FILM:RM 1/8TS 820-J		L403	62427-812-101	COIL-PEAKING:EL0606RA 100UH-J	
R3427	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		L404	62427-812-220	COIL-PEAKING:EL0606RA 22UH-J	
R3430	61048-177-473	R-METAL FILM:RM 1/8TS 47K-J		L405	62427-812-220	COIL-PEAKING:EL0606RA 22UH-J	
R3431	61048-177-273	R-METAL FILM:RM 1/8TS 270-J		L406	62427-812-270	COIL-PEAKING:EL0606RA 2.2UH-J	
R3434	61048-177-271	R-METAL FILM:RM 1/8TS 2.2K-J		L407	62427-812-829	COIL-PEAKING:EL0606RA 8.2UH-J	
R3437	61048-177-332	R-METAL FILM:RM 1/8TS 3.3K-J		Q401	62137-702-010	TRANSISTOR:KSC 945-Y TAPG	
R3438	61048-177-103	R-METAL FILM:RM 1/8TS 1K-J		Q402	62137-302-74C	TRANSISTOR:KSC 945-Y TAPG	
R3439	61048-177-103	R-METAL FILM:RM 1/8TS 10K-J		R401	61048-177-101	R-METAL FILM:RM 1/8TS 100-J	
R3501	61048-177-103	R-METAL FILM:RM 1/8TS 75-J		R402	61048-177-220	R-METAL FILM:RM 1/8TS 22-J	
R3502	61048-177-750	R-METAL FILM:RM 1/8TS 75-J					
R3503	61048-177-750	R-METAL FILM:RM 1/8TS 10K-J					
R3504	61048-177-103	R-METAL FILM:RM 1/8TS 470-J					
R3506	61048-177-471	R-METAL FILM:RM 1/8TS 470-J					
R3507	61048-177-471	R-METAL FILM:RM 1/8TS 470-J					
R3508	61048-177-471	R-METAL FILM:RM 1/8TS 75-J					
R3509	61048-177-750	R-METAL FILM:RM 1/8TS 680-J					
R3510	61048-177-681	R-METAL FILM:RM 1/8TS 390-J					
R3511	61048-177-391	R-METAL FILM:RM 1/8TS 150-J					
R3512	61048-177-151	R-METAL FILM:RM 1/8TS 150-J					

LOC# NO	PART-NUMBER	DESCRIPTION: SPECIFICATION	REMARK	LOC# NO	PART-NUMBER	DESCRIPTION: SPECIFICATION	REMARK
R403	61048-177-101	R-METAL FILM:RM 1/8TS 100-J		R425	61048-177-272	R-METAL FILM:RM 1/8TS 2.7K-J	
R404	61048-177-331	R-METAL FILM:RM 1/8TS 330-J		VR401	61247-101-103	VR-SEMI:EVN-DJA A03 B14 TAPG 10KB	
R405	61048-177-562	R-METAL FILM:RM 1/8TS 5.6K-J		ZD401	62119-501-561	IC-L:KA33V TAPG	
R406	61048-177-681	R-METAL FILM:RM 1/8TS 680-J		AUDIO PARTS			
R407	61048-177-122	R-METAL FILM:RM 1/8TS 1.2K-J		C501	61637-206-100	C-ELEC:CEAP 35V 10M SA(SX11)	
R408	61048-177-820	R-METAL FILM:RM 1/8TS 82-J		C502	61507-121-470	C-POLYESTER:CO921M TAPG 100V 103-K	
R409	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		C503	61637-204-330	C-ELEC:CEAP 16V 33M SA(SX11)	
R410	61048-177-152	R-METAL FILM:RM 1/8TS 270-J		C504	61637-208-010	C-ELEC:CEAP 50V 1M SA(SX11)	
R411	61048-177-271	R-METAL FILM:RM 1/8TS 1.5K-J		C505	61637-208-478	C-ELEC:CEAP 50V 0.47M SA(SX11)	
R412	61048-177-272	R-METAL FILM:RM 1/8TS 2.7K-J		C506	61507-121-360	C-POLYESTER:CO921M TAPG 50V 152-K	
R413	61048-177-151	R-METAL FILM:RM 1/8TS 150-J		C508	61507-121-371	C-POLYESTER:CO921M TAPG 50V 182-J	
R414	61048-177-102	R-METAL FILM:RM 1/8TS 150-J		C509	61407-117-228	C-CERAMIC:AXIAL:CAX SL TAPG 50V 223-Z	
R415	61048-177-393	R-METAL FILM:RM 1/8TS 39K-J		C511	61507-121-480	C-POLYESTER:CO921M TAPG 100V 153-K	
R416	61048-177-821	R-METAL FILM:RM 1/8TS 820-J		C512	61507-121-430	C-POLYESTER:CO921M TAPG 100V 472-K	
R417	61048-177-562	R-METAL FILM:RM 1/8TS 5.6K-J		C513	61507-121-470	C-ELECTROLYTIC:LC-0511-4.7-50-M TAPG	
R418	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J		C514	61607-421-120	C-POLYESTER:CO921M TAPG 50V 333-J	
R419	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J		C517	61507-121-531	C-ELEC:CEAP 50V 1M SA(SX11)	
R420	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J		C518	61637-208-010	C-ELECTROLYTIC:LC-0511-47-16-M TAPG	
R421	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J		C520	61607-421-130	C-ELECTROLYTIC:LC-0511-47-16-M TAPG	
R422	61048-177-472	R-METAL FILM:RM 1/8TS 4.7K-J		C522	61607-421-130	C-ELEC:CEAP 35V 10M SA(SX11)	
R423	61048-177-123	R-METAL FILM:RM 1/4T 2.2K-J		C523	61607-421-130	C-CERAMIC:TEMP:CC45 SL TAPG 50V 330-J	
R424	61048-277-222	R-METAL FILM:RM 1/4T 2.2K-J		C524	61407-101-480	C-POLYESTER:MDX 100V TAPG 473-K	
VR401	61247-101-103	VR-SEMI:EVN-DJA A03 B14 TAPG 10KB		C525	61507-339-010	C-ELECTROLYTIC:LC-0511-47-16-M TAPG	
ZD401	62119-501-561	IC-L:KA33V TAPG		C526	61607-421-130	C-POLYESTER:CO921M TAPG 100V 472-K	
TUNER PARTS : VI-1560				C527	61507-121-430	C-POLYESTER:CO921M TAPG 50V 682-K	
C3520	64519-903-195	TUNER:TERB 7X004A		C528	61507-121-450	C-ELEC:CEAP 16V 10M RSS(4X7)	
C402	62569-002-300	RF-CONVERTER:MDLX8523A		C529	61617-404-100	C-POLYESTER:CO921M TAPG 100V 123-K	
C404	63054-401-821	COAXIAL-CABLE ASSY:7/0.16 300V BLK 180AA		C530	61507-121-630	C-ELEC:CEAP 50V 2.2M SA (SX11)	
C405	61407-105-320	C-CERAMIC:TEMP:CC45 CH TAPG 50V 82-J		C531	61637-208-229	C-POLYESTER:CO921M TAPG 50V 153-J	
C406	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M		C534	61507-121-481	C-CERAMIC:TEMP:CC45 CH TAPG 50V 82-J	
C407	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M		C535	61407-105-320	C-CERAMIC:TEMP:CC45 CH TAPG 50V 82-J	
C408	61407-117-104	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M		C536	61407-105-320	C-CERAMIC:TEMP:CC45 CH TAPG 50V 82-J	
C409	61407-105-250	C-ELECTROLYTIC:LC-0511-4.7-50-M TAPG		CMS01	63053-917-493	LEAD CONNECTOR ASSY:1533 #26 5231-07/500	
C410	61607-421-120	C-POLYESTER:CO921M TAPG 100V 222-K		D501	62169-406-482	DIODE:1N4148 SAMSUNG	
C411	61507-121-390	C-POLYESTER:CO921M TAPG 100V 103-K		IC501	62119-103-685	IC:LA7295	
C412	61507-121-470	C-CERAMIC:AXIAL:CAX Y TAPG 16V 0.01-M		L501	62429-010-280	COIL-PEAKING:BOAH-22MH	
C413	61407-117-104	C-ELECTROLYTIC:LC-0511-47-16-M TAPG		L502	62427-813-153	COIL-PEAKING:EL0607RA 15uH-J	
C414	61607-421-130	C-ELEC:CEAP 50V 1M SA(SX11)		L503	62429-833-101	COIL-PEAKING:AXIAL:BALOAST 101K	
C415	61637-208-100	C-CERAMIC:AXIAL:CAX SL TAPG 50V 223-Z		L504	62427-813-101	COIL-PEAKING:EL0607RA 100uH-K	
C416	61407-117-228	C-CERAMIC:TEMP:CC45 SL TAPG 50V 22-J		Q501	62137-701-011	TRANSISTOR:KSR 1002 TAPG	
C417	61407-101-160	C-POLYESTER:CO921M TAPG 100V 104-M		Q502	62137-701-011	TRANSISTOR:KSC 1008-Y TAPG	
C418	61507-121-920	C-ELEC:CEAP 50V 0.47M SA(SX11)		Q503	62137-702-020	TRANSISTOR:KSC 1008-Y TAPG	
C419	61637-208-478	C-ELEC:CEAP 50V 1M SA(SX11)		Q504	62137-702-020	TRANSISTOR:KSC 1008-Y TAPG	
C420	61637-208-010	C-CERAMIC:TEMP:CC45 CH 50V 20-J		Q507	62137-702-020	TRANSISTOR:KSC 1008-Y TAPG	
C421	61409-105-170	C-ELEC:CEAP 16V 10M RSS(4X7)		R501	61048-177-101	R-METAL FILM:RM 1/8TS 100-J	
C422	61617-404-100	COIL VARIABLE:1.2UH PSF MATCH		R502	61048-177-183	R-METAL FILM:RM 1/8TS 18K-J	
FL403	62429-832-080	TRANS-RESONANT(T1):40MHZ V-DET		R503	61048-177-273	R-METAL FILM:RM 1/8TS 27K-J	
FL404	64529-421-020	CERAMIC-TRAP:TPS-6.0MB		R504	61048-177-333	R-METAL FILM:RM 1/8TS 33K-J	
FL405	64529-310-021	FILTER CERAMIC DISCRIMINATOR:CDA 6.0 ME		R505	61048-177-273	R-METAL FILM:RM 1/8TS 27K-J	
FL406	64529-310-011	FILTER CERAMIC:SFE-6.0MB		R506	61048-177-273	R-METAL FILM:RM 1/8TS 27K-J	
FL407	62719-049-013	TRANS-AFT(T2):40MHZ AFT-BAL		R507	61048-177-332	R-METAL FILM:RM 1/8TS 3.3K-J	
FL408	64529-418-040	FILTER-SAW:TSF 1306		R508	61048-177-273	R-METAL FILM:RM 1/8TS 27K-J	
FL409	62119-103-721	IC:LA7545		R509	61048-177-223	R-METAL FILM:RM 1/8TS 22K-J	
IC401	62427-812-229	COIL-PEAKING:EL0606RA 2.2uH-K		R510	61048-177-822	R-METAL FILM:RM 1/8TS 8.2K-J	
L402	62427-812-101	COIL-PEAKING:EL0606RA 22uH-J		R511	61048-177-475	R-METAL FILM:RM 1/8TS 4.7K-J	
L403	62427-812-220	COIL-PEAKING:EL0606RA 22uH-J		R512	61048-177-512	R-METAL FILM:RM 1/8TS 5.1K-J	
L404	62427-812-220	COIL-PEAKING:EL0606RA 22uH-J		R513	61048-177-334	R-METAL FILM:RM 1/8TS 330K-J	
L405	62427-812-270	COIL-PEAKING:EL0606RA 27uH-J		R514	61048-177-822	R-METAL FILM:RM 1/8TS 8.2K-J	
L406	62427-812-150	COIL-PEAKING:EL0606RA 15uH-J		R515	61048-177-101	R-METAL FILM:RM 1/8TS 100-J	
L407	62137-702-010	TRANSISTOR:KTC 388ATH TAPG		R516	61048-177-821	R-METAL FILM:RM 1/8TS 820-J	
Q401	62137-302-740	TRANSISTOR:KSC 945-Y TAPG		R517	61048-177-152	R-METAL FILM:RM 1/8TS 1.5K-J	
Q402	61048-177-101	R-METAL FILM:RM 1/8TS 100-J		R518	61048-177-479	R-METAL FILM:RM 1/8TS 47K-J	
R401	61048-177-331	R-METAL FILM:RM 1/8TS 330-J		R521	61048-177-821	R-METAL FILM:RM 1/8TS 820-J	
R404	61048-177-331	R-METAL FILM:RM 1/8TS 5.6K-J		R522	61048-177-333	R-METAL FILM:RM 1/8TS 33K-J	
R405	61048-177-562	R-METAL FILM:RM 1/8TS 560-J		R523	61048-177-332	R-METAL FILM:RM 1/8TS 3.3K-J	
R406	61048-177-681	R-METAL FILM:RM 1/8TS 680-J		R526	61048-177-391	R-METAL FILM:RM 1/8TS 20K-J	
R407	61048-177-122	R-METAL FILM:RM 1/8TS 82-J		R527	61048-177-203	R-METAL FILM:RM 1/8TS 10K-J	
R408	61048-177-820	R-METAL FILM:RM 1/8TS 1K-J		R529	61048-177-103	R-METAL FILM:RM 1/8TS 30K-J	
R409	61048-177-102	R-METAL FILM:RM 1/8TS 1.5K-J		R531	61048-177-303	R-METAL FILM:RM 1/8TS 4.7K-J	
R410	61048-177-152	R-METAL FILM:RM 1/8TS 270-J		R533	61048-177-479	R-METAL FILM:RM 1/8TS 360-J	
R411	61048-177-271	R-METAL FILM:RM 1/8TS 2.7K-J		R534	61048-177-361	R-METAL FILM:RM 1/8TS 5.6K-J	
R412	61048-177-222	R-METAL FILM:RM 1/8TS 150-J		R535	61048-177-562	R-METAL FILM:RM 1/8TS 560-J	
R413	61048-177-151	R-METAL FILM:RM 1/8TS 150-J		R536	61048-177-562	R-METAL FILM:RM 1/8TS 560-J	
R414	61048-177-151	R-METAL FILM:RM 1/8TS 150-J		R537	61048-177-561	R-METAL FILM:RM 1/8TS 910-J	
R415	61048-177-102	R-METAL FILM:RM 1/8TS 1K-J		R538	61048-177-911	COIL-BIAS OSC:26900K-K5022YCT	
R416	61048-177-393	R-METAL FILM:RM 1/8TS 39K-J		TS01	62429-014-138	VR-SEMI:RH0615C 47K8	
R417	61048-177-821	R-METAL FILM:RM 1/8TS 820-J		VR501	61246-105-473	DIODE-ZENER:MTZ 5.18	
R418	61048-177-562	R-METAL FILM:RM 1/8TS 5.6K-J		ZD501	62169-403-821		
R419	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J					
R420	61048-177-224	R-METAL FILM:RM 1/8TS 220K-J					
R421	61048-177-104	R-METAL FILM:RM 1/8TS 100K-J					
R422	61048-177-472	R-METAL FILM:RM 1/8TS 4.7K-J					
R423	61048-177-123	R-METAL FILM:RM 1/8TS 12K-J					
R424	61048-277-222	R-METAL FILM:RM 1/4T 2.2K-J					


7. MECHNICAL EXPLODED VIEWS

	Page
7-1. Instrument Assembly	7-2
7-2. Transport Mechanism Assembly.....	7-3
7-3. Bottom Side Mechanism Assembly.....	7-4
7-4. Housing Assembly	7-5


7-1. Instrument Assembly



7-2. Tranport Mechanism Assembly



7-3. Bottom Side Mechanism Assembly




8. BLOCK DIAGRAMS


	Page
8-1. Total Wiring Diagram-----	8-2
8-2. Drum Phase Control -----	8-3
8-3. Drum Speed Control -----	8-3
8-4. Capstan Phase Control-----	8-4
8-5. Capstan Speed Control-----	8-4
8-6. Audio Playback Process-----	8-5
8-7. Audio Record Process-----	8-5
8-8. Luminance Playback Process-----	8-6
8-9. Luminance Record Process-----	8-7
8-10. Chrominance Playback Process-----	8-8
8-11. Chrominance Record Process-----	8-9




8-2. Drum Phase Control




8-3. Drum Speed Control




8-4. Capstan Phase Control




8-5. Capstan Speed Control




8-6. Audio Playback Process




8-7. Audio Record Process




8-8. Luminance Playback Process




8-9. Luminance Record Process



8-10. Chrominance Playback Process



8-11. Chrominance Record Process




9. CIRCUIT BOARDS


	Page
9-1. Regulator (Top Side) -----	9-3
Regulator (Bottom Side) -----	9-4
9-2. Deck Joint (Top Side) -----	9-5
Deck Joint (Bottom Side) -----	9-6
9-3. Reel Sensor (Top Side) -----	9-5
Reel Sensor (Bottom Side) -----	9-6
9-4. Loading Motor (Top Side) -----	9-7
Loading Motor (Bottom Side) -----	9-8
9-5. Cassette LED (Top Side) -----	9-7
Cassette LED (Bottom Side) -----	9-8
9-6. Start / End Sensor (Top Side) -----	9-9
Start / End Sensor (Bottom Side) -----	9-10
9-7. A/C Head (Top Side) -----	9-9
A/C Head (Bottom Side) -----	9-10
9-8. Remote Control (VX/VI-1560) (Top Side) -----	9-11
Remote Control (VX/VI-1560) (Bottom Side) -----	9-12
9-9. Remote Control (VX-1561) (Top Side) -----	9-11
Remote Control (VX-1561) (Bottom Side) -----	9-12
9-10. Sync DET (OPTION) (Top Side) -----	9-11
Sync DET (OPTION) (Bottom Side) --	9-12

1	AC 4.2V
2	AC 4.2V
3	-30V
4	GND
5	GND
6	AL 40V
7	AL 5.8V
8	AL 12V
9	MOTOR GND
10	MOTOR AL 15V


FROM MAIN CN101




9-3. Reel Sensor (Top Side)




9-2. Deck Joint (Bottom Side)




9-3. Reel Sensor (Bottom Side)




9-4. Loading Motor (Top Side)




9-5. Cassette LED (Top Side)




9-4. Loading Motor (Bottom Side)




9-5. Cassette LED (Bottom Side)




9-6. Start/End Sensor (Top Side)




9-7. A/C Head (Top Side)




9-6. Start / End Sensor (Bottom Side)




9-7. A/C Head (Bottom Side)




9-8. Remote Control (VX/VI-1560)
(Top Side)




9-9. Remote Control (VX-1561) (Top Side)




9-10. Sync DET (OPTION) (Top Side)



9-11. Pre-Amp (Bottom Side)




9-12. VPS (OPTION) (Bottom Side)




9-14

9-13. OSD (OPTION) (Top Side)




9-14. CAP. FG AMP (Top Side)




9-15

9-9. Remote Control (VX-1561)
(Bottom Side)



9-8. Remote Control (VX/VI-1560)
(Bottom Side)



9-10. Sync DET (OPTION) (Bottom Side)


CN3601
NON OSD PCB

6	OSD ST
7	OSD. V. OUT
8	GND
9	OSD. V. IN
10	AL 5V
11	PC 5V
12	SYNC DET
13	PC 12V
14	C. SYNC


FROM MAIN
CN3202

9-12

9-11. Pre-Amp (Top Side)



9-12. VPS (OPTION) (Top Side)




9-13

9-15. LP SKEW (Bottom Side)

CN3205	
1	PC 12V
2	SKEW. V. OUT
3	GND
4	SKEW. V. IN
5	C. SYNC
6	PC 5V
7	DL PB 5V
8	LP (H)
9	NTSC (H)
10	MESECAM (H)
11	SECAM (H)
12	SKEW C. OUT
13	TRICK (H)
14	SKEW C. IN
15	APC ERROR
16	FSC

FROM MAIN
CN3204



9-17. Timer (VX/VI-1560) (Top Side)

CN703	
1	DMC 1
2	DMC 2
3	H D SW
4	ENV. DET
5	CAP FG CD
6	CTL CD
7	OUT EXP ST
8	H. A. SW
9	S. CLK
10	S. D. O
11	GND
12	AC 4.2V
13	BU 5V
14	STEP/SLOW
15	CM LIMIT
16	DUTY I/O
17	VPS DI
18	V. ENV
19	SYNC DET
20	VPS CK


FROM MAIN
CN206

CN702	
1	PC 5V
2	GND
3	AC 4.2V
4	C. CLK
5	C. D. O
6	IN EXP ST
7	ROTARY SW
8	PLL ST
9	-30V
10	GND
11	AFT
12	C. D. I
13	OSD ST
14	GND
15	GND
16	AL 5V
17	NTSC (H)
18	SECAM (H)
19	PAL MES (H)
20	PICTURE


FROM MAIN
CN205

CN701		
1	S2	1
2	S7	2
3	S6	3
4	KEY 1	4
5	S5	5
6	KEY 2	6
7	S4	7
8	KEY 3	8
9	S9	9
10	S8	10


FROM FUNC
CN704




9-13. OSD (OPTION) (Bottom Side)





9-15. LP SKEW (Top Side)




9-14. CAP. FG AMP (Bottom Side)



9-16. Main (Top Side)





(1)

CN205

1	PC 5V
2	GND
3	AC 4.2V
4	C.CLK
5	C.D.O
6	IN EXP ST
7	ROTARY SW
8	PLL ST
9	-30V
10	GND
11	AFT
12	C.D.I
13	OSD ST
14	GND
15	GND
16	AL 5V
17	NTSC (H)
18	SECAM (H)
19	PAL MES (H)
20	PICTURE

FROM TIMER
CN702

(2)

CN206

1	DMC 1
2	DMC 2
3	H'D SW
4	ENV.DET
5	CAP FG CD
6	CTL CD
7	OUT EXP ST
8	H.A. SW
9	S.CLK
10	S.D.O
11	GND
12	AC 4.2V
13	BU 5V
14	STEP/SLOW
15	CM LIMIT
16	DUTY I/O
17	VPS DI
18	V. ENV
19	SYNC DET
20	VPS CK

FROM TIMER
CN703

(3)

CN101

1	-20V AC 4.2V
2	-20V AC 4.2V
3	-30V
4	GND
5	GND
6	PRST VTG 33V
7	AL 5.8V
8	AL 12V
9	MOTOR GND
10	MOTOR AL 15V

FROM
REG ASSY
CN102

(4)

CN203

1	GND
2	CTL (+)
3	CTL (-)

FROM A.C
CN001

(5)

CN209

1	CAP FG IN
2	PC 5V
3	GND
4	CAP FG OUT

FROM CAP FG AMP
CN210

(6)

CN201

1	PC 5V
2	R/F
3	C.FG
4	CTL REF
5	CM CTL
6	I.LIMIT
7	C.MOTOR B ⁺
8	MOTOR GND
9	I.C. GND

FROM DECK J
CN6205



(7)

CN202

1	D.PG
2	GND
3	D.FG
4	D.MOTOR B ⁺
5	DM CTL
6	MOTOR GND

FROM
DRUM MOTOR (CN1)

9-16. Main (Bottom Side)




9-17. Timer (VX/VI-1560) (Bottom Side)


CN701			CN702			CN703		
1	S2	1	1	PC 5V		1	DMC 1	
2	S7	2	2	GND		2	DMC 2	
3	S6	3	3	AC 4.2V		3	H'D SW	
4	KEY1	4	4	C. CLK		4	ENV. DET	
5	S5	5	5	C.D.O		5	CAP FG CD	
6	KEY2	6	6	IN EXP ST		6	CTL CD	
7	S4	7	7	ROTARY SW		7	OUT EXP ST	
8	KEY3	8	8	PLL ST		8	H.A. SW	
9	S9	9	9	-30V		9	S. CLK	
10	S8	10	10	GND		10	S.D.O	
FROM FUNC CN704			11	AFT		11	GND	
			12	C.D. I		12	AC 4.2V	
			13	OSD ST		13	BU 5V	
			14	GND		14	STEP/SLOW	
			15	GND		15	CM LIMIT	
			16	AL 5V		16	DUTY I/O	
			17	NTSC (H)		17	-VPS DI	
			18	SECAM (H)		18	V. ENV	
			19	PAL MES (H)		19	SYNC DET	
			20	PICTURE		20	VPS CK	
			FROM MAIN CN205			FROM MAIN CN206		

9-18. Timer (VX-1561) (Top Side)


CN701			CN702			CN703		
1	NC		1	PC 5V		1	DMC 1	
2	KEY IN 1		2	GND		2	DMC 2	
3	KEY IN 2		3	AC 4.2V		3	H'D SW	
4	KEY IN 3		4	C. CLK		4	ENV. DET	
5	J (S7)		5	C.D.O		5	CAP FG CD	
6	I (S8)		6	IN EXP ST		6	CTL CD	
7	H (S9)		7	ROTARY SW		7	OUT EXP ST	
8	D (S4)		8	PLL ST		8	H.A. SW	
9	C (S2)		9	-30V		9	S. CLK	
10	NC		10	GND		10	S.D.O	
11	NC		11	AFT		11	GND	
FROM FUNC CN704			12	C.D. I		12	AC 4.2V	
			13	OSD ST		13	BU 5V	
			14	GND		14	STEP/SLOW	
			15	GND		15	CM LIMIT	
			16	AL 5V		16	DUTY I/O	
			17	NTSC (H)		17	VPS DI	
			18	SECAM (H)		18	V. ENV	
			19	PAL MES H		19	SYNC DET	
			20	PICTURE		20	VPS CK	
			FROM MAIN CN205			FROM MAIN CN206		




9-18. Timer (VX-1561) (Bottom Side)




9-19. Function (VX/VI-1560) (Top Side)




9-20. Function (VX-1561) (Bottom Side)




9-21. Speed SUB (OPTION) (Top Side)



9-19. Function (VX/VI-1560) (Bottom Side)




9-20. Function (VX-1561) (Top Side)



REGULATOR

REGULATOR

10-1. Regulator



SPECIAL NOTE

All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.


NOTE

Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

IMPORTANT SAFETY NOTICES
Components identified with the mark (Δ) have the special characteristics for safety when replacing any of these components. Use only the same type.


	Q101			Q102			Q103		
	E	C	B	E	C	B	E	C	B
STOP	15.4	18.5	16.04	5.9	8.8	6.5	-30.1	-30.1	-30.1
PB	15.3	15.1	16.0	5.9	8.6	6.5	-30.1	-30.1	-30.1
REC	15.3	17.5	15.9	5.9	8.6	6.5	-30.1	-30.2	-30.1

9-21. Speed SUB (OPTION) (Bottom Side)



10. SCHEMATIC DIAGRAMS


	Page
10-1. Regulator-----	10-2
10-2. Timer (VX/VI-1560)-----	10-3
10-3. Timer (VX-1561)-----	10-3
10-4. Servo/Power/System Control-----	10-4
10-5. Luminance/Chrominance-----	10-6
10-6. Audio-----	10-8
10-7. Tuner (VI Model)-----	10-8
10-8. Tuner/VPS (VX Model)-----	10-9
10-9. Pre Amp-----	10-10
10-10. LP Skew-----	10-11
10-11. OSD (OPTION)-----	10-12
10-12. Deck Joint-----	10-13
10-13. Function (VX/VI-1560)-----	10-14
10-14. Function (VX-1561)-----	10-14
10-15. Speed SUB (OPTION)-----	10-15
10-16. Remote Control-----	10-16



NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.


SPECIAL NOTE




* ALL DIODE ARE 1N4148

TUNER


10-3. Timer



SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.



TIMER



TIMER

J-RPS : JET REVERSE SEARCH


J-FPS : JET FORWARD SEARCH

MODE PIN NO	IC701								
	STOP	PLAY	REC	REW	FWD	APS	J-APS	J-FPS	STILL
PIN 1			-30V _ +5V				T=3.6msec		
PIN 2			-30V _ +5V				T=3.6msec		
PIN 3			-30V _ +5V				T=3.6msec		
PIN 4			-30V _ +5V				T=3.6msec		
PIN 5					5V				
PIN 6					0V				
PIN 7		0V _ +4.7V					T=3.6msec		
PIN 8		0V _ +4.7V					T=3.6msec		
PIN 9		0V _ +5V					T=40msec		
PIN 10					0V				
PIN 11		0V _ +5V							
PIN 12		0V _ +5V					T=40msec		
PIN 13					0V				
PIN 14					0V		T=27msec		
PIN 15		0V _ +5V					T=40msec		
PIN 16		0V _ +5V					T=40msec		
PIN 17					5V				
PIN 18					0V				
PIN 19					2.3V				
PIN 20					2.3V				
PIN 21					5V				
PIN 22					5V				
PIN 23					5V				
PIN 24					5V				
PIN 25					5V				
PIN 26					5V				
PIN 27					0V _ +5V				
PIN 28					5V				
PIN 29					0V				
PIN 30		+0.6V _ +4.4V					T=0.25usec		
PIN 31		0V _ +5V					T=0.25usec		
PIN 32					0V				
PIN 33					1.6V				
PIN 34		0V _ +5V					T=30usec		
PIN 35		0V _ +5V					T=40usec		
PIN 36		0V _ +5V					T=40usec		
PIN 37		0V _ +5V							
PIN 38		0V _ +5V							
PIN 39		5V							
PIN 40		-30V _ +5V					T=3.6msec		
PIN 41		-30V _ +5V					T=3.6msec		
PIN 42		-30V _ +5V					T=3.6msec		
PIN 43		-30V _ +5V					T=3.6msec		
PIN 44		-30V _ +5V					T=3.6msec		
PIN 45		-30V _ +5V					T=3.6msec		
PIN 46		-30V _ +5V					T=3.6msec		
PIN 47		-30V _ +5V					T=3.6msec		
PIN 48		-30V _ +5V					T=3.6msec		
PIN 49		-30V _ +5V					T=3.6msec		
PIN 50		-30V _ +5V					T=3.6msec		
PIN 51		-30V _ +5V					T=3.6msec		
PIN 52		-30V _ +5V					T=3.6msec		
PIN 53		-30V _ +5V					T=3.6msec		
PIN 54		0V							
PIN 55		0V							
PIN 56		-30V _ -20V							
PIN 57		0V							
PIN 58		-30V _ +5V					T=3.6msec		
PIN 59		-30V _ +5V					T=3.6msec		
PIN 60		-30V _ +5V					T=3.6msec		
PIN 61		-30V _ +5V							
PIN 62		-30V _ +5V							
PIN 63		-30V _ +5V							
PIN 64		5V							

**SERVO / POWER /
SYSTEM CONTROL**

**SERVO / POWER /
SYSTEM CONTROL**


10-4. Servo / Power / System Control




LUMINANCE/ CHROMINANCE

LUMINANCE/ CHROMINANCE

10-5. Luminance/Chrominance



SERVO/POWER/ SYSTEM CONTROL




NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.

PIN NO	MODE	STOP
PIN 1	3.5	
PIN 2	0	
PIN 3	0	
PIN 4	5	
PIN 5	0	
PIN 6	0	
PIN 7	2	
PIN 8	0	
PIN 9	2.5	
PIN 10	2.5	
PIN 11	5	
PIN 12	2.4	
PIN 13	2.4	
PIN 14	2.4	
PIN 15	2.5	
PIN 16	2.5	
PIN 17	2.5	
PIN 18	2.5	
PIN 19	0.1	
PIN 20	5	
PIN 21	2.5	
PIN 22	0	
PIN 23	0	
PIN 24	0	
PIN 25	0.5	
PIN 26	5	
PIN 27	5	
PIN 28	5	
PIN 29	2.5	
PIN 30	2.5	
PIN 31	0	
PIN 32	2.5	
PIN 33	2.5	
PIN 34	2.5	
PIN 35	2.5	
PIN 36	2.5	
PIN 37	2.7	
PIN 38	5	
PIN 39	0	
PIN 40	0	
PIN 41	5	
PIN 42	2.6	
PIN 43	0.5	
PIN 44	2.5	
PIN 45	2.5	
PIN 46	2.5	
PIN 47	2.5	
PIN 48	0	
PIN 49	0	
PIN 50	0	
PIN 51	5	
PIN 52	5	
PIN 53	5	
PIN 54	5	
PIN 55	5	
PIN 56	0	

SERVO / POWER / SYSTEM CONTROL



RPS : REVERSE SEARCH

J-RPS : JET REVERSE SEARCH

J-FPS : JET FORWARD SEARCH

MODE PIN NO	IC201									
	STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL	
PIN 1	3.5	3.5	3.5	3.5	3.5	3.5	3.5	0	3.5	
PIN 2	0	0	0	0	0	0	0	0	0	
PIN 3	0	0	0	0	0	0	0	0	0	
PIN 4	5	5	5	5	5	5	5	5	5	
PIN 5	0	0	0	0	0	0	0	0	0	
PIN 6	0	0	0	0	0	0	0	0	0	
PIN 7	2	2	2.1	2.1	2.1	2	2	2	2	
PIN 8	0	0	0	0	0	0	0	0	0	
PIN 9	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	
PIN 10	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	
PIN 11	5	5	5	5	5	5	5	5	5	
PIN 12	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	
PIN 13	2.4	2.4	2.5	2.5	2.4	2.3	2.2	2.6	2.4	
PIN 14	2.4	2.4	2.5	2.5	2.4	2.3	2.2	2.6	2.4	
PIN 15	2.5	2.4	2.5	2.5	2.4	2.3	2.2	2.6	2.4	
PIN 16	2.5	2.5	2.5	2.5	2.4	2.3	2.2	2.6	2.4	
PIN 17	2.5	2.5	2.5	2.5	2.5	2.3	2.2	2.6	2.4	
PIN 18	2.5	2.3	2.4	2.4	2.4	2.3	2.3	2.6	2.4	
PIN 19	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	
PIN 20	5	2.5	2.5	2.5	2.5	2.5	0.1	2.5	5	
PIN 21	2.5	2.5	2.5	2.5	0	2.5	0.1	2.5	2.5	
PIN 22	0	2.5	2.5	2.5	2.5	2.5	2.4	2.5	0	
PIN 23	0	2.5	2.5	0	2.5	2.5	2.4	2.5	1.8	
PIN 24	0	2.5	2.5	0	2.5	2.5	2.5	2.5	0.2	
PIN 25	0.5	2.5	2.5	2.4	2.5	2.5	2.4	2.5	2.5	
PIN 26	5	2.5	2.5	2.6	2.6	2.6	2.7	2.6	2.4	
PIN 27	5	2.6	2.6	2.6	2.6	2.6	2.7	2.6	3.2	
PIN 28	5	5	5	5	5	5	5	5	5	
PIN 29	2.5	2.4	2	2.4	2.4	2.4	2.5	2.4	2.4	
PIN 30	2.5	2.5	3	2.4	2.4	2.4	2.4	2.4	2.4	
PIN 31	0	0	0	0	0	0	0	0	0	
PIN 32	2.5	2.5	2.5	2.4	2.4	2.4	2.4	2.5	2.4	
PIN 33	2.5	2.5	2.5	2.4	2.4	2.4	2.4	2.5	2.4	
PIN 34	2.5	2.5	2.5	0	0	0	0	0	0	
PIN 35	2.5	2.5	2.5	2.5	2.6	2.6	2.4	2.6	2.4	
PIN 36	2.5	2.5	2.5	2.5	2.6	2.6	2.4	2.6	2.4	
PIN 37	2.7	2.7	2.6	2.6	2.6	2.6	2.6	2.6	2.6	
PIN 38	5	5	5	5	5	5	5	5	5	
PIN 39	0	0	3.6	2.5	2.5	0	3	0	5	
PIN 40	0	5	5	5	5	5	0	5	5	
PIN 41	5	5	5	5	5	5	0	5	5	
PIN 42	2.6	2.6	2.6	2.6	2.6	2.6	2.6	2.6	2.6	
PIN 43	0.5	2.5	2.5	2.6	2.6	2.6	2.6	2.6	2.6	
PIN 44	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	
PIN 45	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	
PIN 46	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	
PIN 47	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5	
PIN 48	0	0	0	0	0	0	0	0	0	
PIN 49	0	0	0	0	0	5	5	5		
PIN 50	0	0	0.4	0.4	0.4	0.4	0.4	0.4	0.4	
PIN 51	5	5	5	5	5	5	5	5	5	
PIN 52	5	5	5	5	5	5	5	5	5	
PIN 53	5	5	5	5	5	5	5	5	5	
PIN 54	5	5	5	5	5	5	5	5	5	
PIN 55	5	0	2.5	2.5	0	0	2.5	0	5	
PIN 56	0	0	5	2.5	2.5	0	2.5	0	5	

SERVO/POWER/ SYSTEM CONTROL

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH

PIN NO	MODE	IC204								
		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1	0	0	0	0	0	0	0	0	0	0
PIN 2	1.6	1.7	1.9	1.9	1.9	1.1	1.2	1.1	1.7	
PIN 3	3	3	3.2	3.2	3.2	2	2	2	2	
PIN 4	0	0	5	5	0	0	4.7	4.8	5	
PIN 5	0	5	4.9	4.9	0	0	4.7	4.7	5	
PIN 6	0	0	0	0	4.9	4.8	4.7	4.8	0	
PIN 7	0	0	5	0	0	5	5	5	0	
PIN 8	0	0	0	0	0	0	0	0	0	
PIN 9	3	3	3.2	3.2	3.2	1.7	1.7	1.7	2	
PIN 10	1.7	1.7	1.7	1.7	1.7	1.9	1.9	1.7	1.1	
PIN 11	0	5	5	5	5	0	0	0	5	
PIN 12	0	5	5	5	5	0	0	0	5	
PIN 13	0	5	5	0	5	0	0	0	5	
PIN 14	0	0	0	0	0	5	5	0	0	
PIN 15	4.2	5	5	5	5	4.1	4.1	4.2	5	
PIN 16	5	0	5	5	5	5	5	5	5	

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH












PIN NO	MODE	IC205								
		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1	0	0	0	0	0	0	0	0	0	0
PIN 2	0	1.7	1.7	1.8	1.7	1.9	1.9	1.9	1.1	
PIN 3	3	3	3.2	3.2	3.2	2	2	2	0	
PIN 4	5	5	0	0	0	0	5	5	4.7	
PIN 5	5	0	0	0	0	0	4.9	5	0	
PIN 6	0	0	0	0	0	0	0	0	5	
PIN 7	0	0	0	0	0	0	0	0	0	
PIN 8	0	0	0	0	0	0	0	0	0	
PIN 9	3	3	3.1	3.2	3	2	2	2	1.7	
PIN 10	1.7	1.7	1.9	1.9	1.9	1.1	1.1	1.1	1.9	
PIN 11	5	0	0	0	0	0	5	5	0	
PIN 12	5	0	0	0	0	0	5	5	5	
PIN 13	5	0	0	4.6	4.6	5	0	5	0	
PIN 14	0	0	0	5	0	0	0	0	0	
PIN 15	5	4.2	4.1	4.1	4.1	5	5	5	4.1	
PIN 16	5	5	5	5	5	5	5	5	5	

	Q104			Q105			Q107		
	E	C	B	E	C	B	E	C	B
STOP	12.2	12.1	11.4	5.88	5.80	5.1	0	0	0
PB	12.2	12.1	11.4	5.87	5.80	5.1	0	0	0
REC	12.17	12.1	11.38	5.86	5.80	5.09	0.2	-0.43	10.99

SERVO/POWER/ SYSTEM CONTROL

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH

T R	MODE	STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL	FPS
Q210 A733	E	0.6	0.6	0.6	0.6	0.5	0.6	0.6	0.6	0.6	0.6
	B	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
	C	0	0	0	0	0	0	0	0	0	0
Q211 A733	E	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8
	B	14	14	14	14	14	14	14	14	14	14
	C	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
Q212 C945	E	14	14	14	14	14	14	14	14	14	14
	B	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8
	C	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8	14.8
Q213 R1004	E	0	0	0	0	0	0	0	0	0	0
	B	5	5	5	5	5	5	5	5	5	5
	C	0	0	0	0	0	0	0	0	0	0
Q216 D261	E	0	0	0	0	0	0	0	0	0	0
	B	0	0	0.7	0.7	0.7	0.7	0.7	0.7	0	0
	C	15	15	0	0	0	0	0	0	15	15
Q215 A928	E	15	15	14.5	14.5	14.5	14.5	14.5	14.5	15	15
	B	15	15	15	15	15	15	15	15	15	15
	C	13.6	13.6	15	15	15	15	15	15	13.6	13.6
Q205 R1003	E	0	0	0	0	0	0	0	0	0	0
	B	0	0	5	5	5	5	5	5	0	0
	C	5	5	0	0	0	0	0	0	5	5
Q214 R1004	E	0	0	0	0	0	0	0	0	0	0
	B	5	5	5	5	5	5	5	5	5	5
	C	0	0	0	0	0	0	0	0	0	0
Q209 C945	E	4	4	4	4	4	4	4	4	4	4
	B	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5	4.5
	C	5	5	5	5	5	5	5	5	5	5



LUMINANCE/ CHROMINANCE

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH

MODE		IC3401								
PIN NO		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1		0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
PIN 2		1.5	1.4	1.4	1.4	1.4	1.4	1.4	1.3	1.4
PIN 3		3	3	3.1	3.1	3.1	3	3	3	3
PIN 4		2.5	2.5	2.5	2.5	2.5	2.4	2.4	2.4	2.4
PIN 5		1.7	2.5	1.7	1.6	1.7	2.6	2.6	2.6	2.6
PIN 6		0	0	0	0	0	0	0	0	0
PIN 7		3	3	3.1	3.1	3	3	3	3	3
PIN 8		2.9	2.8	2.8	2.8	2.8	2.8	2.8	2.8	2.8
PIN 9		1.8	3.8	1.8	1.8	1.8	3.8	3.8	3.9	3.9
PIN 10		2.9	2.8	2.8	2.8	2.8	2.8	2.8	2.8	2.8
PIN 11		2.6	2.5	2.5	2.5	2.5	2.5	2.5	2.5	2.5
PIN 12		2	1.9	1.9	1.9	1.9	2	2	2	2
PIN 13		4.6	4.6	4.6	4.6	4.6	4.5	4.5	4.5	4.6
PIN 14		0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4	0.4
PIN 15		2.3	2.3	2.3	2.3	2.3	4.2	4.2	4.2	4.2
PIN 16		5	4.9	4.9	4.9	4.8	4.8	4.8	4.8	4.8
PIN 17		4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
PIN 18		2.9	2.3	2.9	2.9	2.9	2.2	2.2	2.2	2.2
PIN 19		3.9	3.8	3.9	3.9	3.9	3.8	3.8	3.8	3.8
PIN 20		5	5	5	5	5	4.9	5	4.9	5
PIN 21		1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6	1.6
PIN 22		1.9	1.9	1.9	1.9	1.9	1.9	1.9	1.9	1.9
PIN 23		2.2	1.7	2.2	2.2	1.7	1.7	1.7	1.7	1.8
PIN 24		2.1	2.3	3.1	3.1	3.1	3.3	3.3	3.3	3.3

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH

MODE		IC3402								
PIN NO		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1		3.7	3.7	3.7	3.7	3.7	3.7	3.7	3.7	3.7
PIN 2		0.3	1.2	0.3	0.3	0.3	1.2	1.2	1.2	1.2
PIN 3		0	0	0	0	0	0	0	0	0
PIN 4		3.7	3.7	3.7	3.7	3.7	3.7	3.7	3.7	3.7
PIN 5		5.1V  0.2V								
PIN 6		0	0	0	0	0	0	0	0	0
PIN 7		3.9	3.9	3.9	3.9	3.9	3.9	3.9	3.9	3.9
PIN 8		0	0	0	0	0	0	0	0	0
PIN 9		3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2
PIN 10		0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
PIN 11		3.8	3.8	3.8	3.8	3.8	3.8	3.8	3.8	3.8
PIN 12		0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
PIN 13		3.8	3.8	3.8	3.8	3.8	3.8	3.8	3.8	3.8
PIN 14		0	0	0	0	0	0	0	0	0
PIN 15		0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
PIN 16		4.5 : MESECAM (H) 0.1 : PAL (L)								
PIN 17		5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1
PIN 18		5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1

LUMINANCE/ CHROMINANCE

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH

MODE		IC3201 (LA7323)								
PIN NO		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1		2.2	3.6	2.2	2.2	2.2	3.5	2.5	3.6	3.5
PIN 2		2.5	2.6	2.5	2.5	2.5	2.6	2.6	2.6	2.6
PIN 3		2.5	2.2	2.5	2.5	2.5	2.2	2.2	2.2	2.2
PIN 4		3.3	2.7	3.3	3.3	3.3	4.5	4.5	4.5	4.5
PIN 5		2.7	4.5	2.7	2.7	2.7	4.5	4.5	4.5	4.5
PIN 6		3.4	1.6	3.5	3.4	3.4	1.4	1.4	1.4	1.4
PIN 7		2.9	2.4	2.8	2.7	2.7	2.4	2.4	2.4	2.4
PIN 8		0	0	0	0	0	0	0	0	0
PIN 9		1	3.4	1	0.8	0.8	3.4	3.4	3.4	3.4
PIN 10		3.1	3.4	3.2	3.2	3.2	3.4	3.4	3.4	3.4
PIN 11		3.7	0.2	3.4	3.6	3.7	3.8	3.7	3.7	3.7
PIN 12		2.9	2.9	3	3	3	2.9	3	3	3
PIN 13		4.4	3.2	4.4	4.4	4.4	3.3	3.3	3.4	3.4
PIN 14		4.4	3.2	4.4	4.4	4.4	3.3	3.2	3.4	3.4
PIN 15		4.4	4	4.4	4.4	4.4	4	4	4	4
PIN 16		3.5	3.4	4.4	3.4	3.4	3.4	3.4	3.4	3.4
PIN 17		0.4	0.3	0.4	0.4	0.4	0.4	0.4	0.4	0.4
PIN 18		2.5	2.4	2.5	2.5	2.5	2.5	2.5	0	2.5
PIN 19		4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2	4.2
PIN 20		0	0	0	0	0	0.1	0.1	0.1	0.1
PIN 21		2.6	2.4	2.5	2.5	2.5	2.4	2.4	2.4	2.4
PIN 22		5	5	5	5	5	5	5	5	5
PIN 23		3.5	3.2	3.6	3.6	3.5	3.2	3.2	3.2	3.2
PIN 24		3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2	3.2
PIN 25		2.9	3.6	2.9	2.9	2.9	3.7	3.7	3.7	3.7
PIN 26		3.5	3.6	3.5	3.5	3.5	3.6	3.6	3.6	3.6
PIN 27		1.4	0.8	1.5	1.5	1.5	0.8	0.8	0.8	0.8
PIN 28		0	0.1	0	0	0	0.1	0.1	0.1	0.1
PIN 29		5	5	5	5	5	5	5	5	5
PIN 30		3.4	4	3.4	3.4	3.4	4	4	4	4

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH

MODE PIN NO		IC3202 (MSM7401RS)								
		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1		0	8.6	0	0	0	8.6	8.6	8.6	8.6
PIN 2		0	0	0	0	0	0	0	0	0
PIN 3		0	8.6	0	0	0	8.6	8.6	8.6	8.6
PIN 4		0	3.0	0	0	0	3.0	3.3	3.3	3.3
PIN 5		3.0	3.3	0.6	3.1	3.0	3.3	3.3	3.3	3.3
PIN 6		0.3	2.2	0.3	0.4	0.4	2.2	2.2	2.2	2.2
PIN 7		0	1.6	0	0	0	1.6	1.6	1.6	1.6
PIN 8		0	4.9	0	0	0	4.9	4.9	4.9	4.9


IC3501(KA8403)									
PIN MODE	1	2	3	4	5	6	7	8	9
STOP	8.2	4.8	8.2	0	0	8.2	0	7.5	11.9
REC	8.2	4.8	8.2	0	0	8.2	0	7.5	11.9
PLAY	8.2	4.8	8.2	0	0	8.2	8.8	7.5	11.9

AUDIO

AUDIO

AUDIO


10-6. Audio




10-8

REV.S : REVERSE SEARCH
FWD.S : FORWARD SEARCH


IC 501							
MODE PIN NO	STOP	REC	PLAY	REW	F. FWD	REV. S	FWD. S
PIN 1	0	10.8	OPEN	0	0	OPEN	OPEN
PIN 2	0	4.6	0	0	0	0	0
PIN 3	0	0	0	0	0	0	0
PIN 4	0	0	0	0	0	0	0
PIN 5	8	8	8	8	8	8	8
PIN 6	9	9	9	9	9	9	9
PIN 7	0	0	0	0	0	0	0
PIN 8	12	12	12	12	12	12	12
PIN 9	0	0	0	0	0	0	0
PIN 10	0	0	4.6	0	0	4.6	4.6
PIN 11	0	0	0	0	0	0	0
PIN 12	0	0	0	0	0	0	0
PIN 13	0	0	0	0	0	0	0
PIN 14	0	0	0	0	0	0	0
PIN 15	2.2	2.2	2.2	2.2	2.2	2.2	2.2
PIN 16	0	0	0	0	0	0	0
PIN 17	2.4	2.4	2.4	2.4	2.4	2.4	2.4
PIN 18	0	0	0	0	0	0	0
PIN 19	0	0	0	0	0	0	0
PIN 20	4	4	4	4	4	4	4
PIN 21	2.4	2.4	2.4	2.4	2.4	2.4	2.4
PIN 22	1.4	1.4	1.4	1.4	1.4	1.4	1.4
PIN 23	0	0	0	0	0	0	0
PIN 24	0	0	0	0	0	0	0
PIN 25	0	0	0	0	0	0	0
PIN 26	0	0	0	0	0	0	0
PIN 27	0.34	0.34	0.34	0.34	0.34	0.34	0.34
PIN 28	0	0	0	0	0	0	0
PIN 29	0	0	0	0	0	0	0
PIN 30	4	4	4	4	4	4	4





IC501-20
REC AMP IN/0.75Vp-p
REC




IC501-25
AUDIO IN 100mVp-p




TP501
REC BIAS/6Vp-p
REC

TP502
EE AUDIO OUT/1.7Vp-p
EE

TP502
PB AUDIO OUT/1.2Vp-P
PB



TP502
REC AUDIO OUT:1.4Vp-p
REC



SCART JACK
AUDIO IN/1.8Vp-p

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.


NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

TUNER/VPS

TUNER/VPS

TUNER/VPS

10-8. Tuner/VPS (VX Model)



NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.


PIN NO	IC6101			
	STOP	PLAY	REC	VPS TIMER REC
PIN 1	+2V	+3.5V		
PIN 2	+2V	+3.5V		
PIN 3	0V			
PIN 4	0V			
PIN 5	+4.5V	+5V	T=10msec	
PIN 6	0V	+4.6V		
PIN 7	5V			
PIN 8	5V	+0V	+5V	
PIN 9	5V	+0V	+5V	
PIN 10	5V			
PIN 11	0V			
PIN 12	5V	+0V	+5V	T=40msec
PIN 13	0.8V			
PIN 14	5V			
PIN 15	5V			
PIN 16	5V			
PIN 17	1.2V			
PIN 18	0V			

PRE-AMP

PRE-AMP


PRE-AMP

10-9. Pre Amp




PIN NO.	MODE		
	STOP	PLAY	REC
PIN 1	0.21	0.2	5
PIN 2	5	H. SW25-H	
PIN 3	0.8	0	0
PIN 4	0	0	0
PIN 5	0	0	1.5
PIN 6	0	0	1.5
PIN 7	0	0	1.2
PIN 8	0	0	0
PIN 9	0	0	0
PIN 10	0	6.8	0
PIN 11	0.4Vpp	5.8+0.4Vpp	0
PIN 12	0	6+0.2Vpp	0
PIN 13	0	0	0
PIN 14	0	12	0
PIN 15	0	6	0.2
PIN 16	0	6+6Vpp	0
PIN 17	0	0.4	0
PIN 18	0	0.4	0
PIN 19	0	0	0
PIN 20	0	0	0
PIN 21	0	0	0
PIN 22	0	0	0
PIN 23	0	0	0
PIN 24	0	0	4
PIN 25	0	0	0
PIN 26	0	0	2
PIN 27	0	0	0.8
PIN 28	0	0	0.8
PIN 29	0	0	2
PIN 30	0	4Vpp	0


RED ——— PB Luminance
BLUE - - - - - PB Color
RED - - - - - REC Luminance
BLUE - - - - - REC Color




IC3101-3
ENV/2Vp-p
PB




IC3102-1
REC FM/150mVp-p
REC



WAFER CN3102-3
REC FM/350mVp-p
REC



WAFER CN3102-4
ENV/300mVp-p
PB



WAFER CN3102-5
FM DET/0.5Vp-p
PB

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.


NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

10-11. OSD (OPTION)

O S D

O S D

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH



NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.

ALL DIODE ARE IN4148 (D901 - D0905)

MODE		IC901								
PIN NO	STOP	FF	REW	PLAY	FPS	RPS	J-FPS	J-RPS	STILL	REC
PIN 1	+1.8V _ +4V									
PIN 2	+1.8V _ +2.8V									
PIN 3	2.8V									
PIN 4	-0.5V _ +4V						T=62usec			
PIN 5	+0.5V _ +4.6V						T=62usec			
PIN 6	+2.5V _ +5V									
PIN 7	+2V _ +4.4V									
PIN 8	0V									
PIN 9	0V _ +5V						T=20msec			
PIN 10	0V _ +5V						T=20msec			
PIN 11	+0.5V _ +2.8V						T=62usec			
PIN 12	2.2V									
PIN 13	4.8V									
PIN 14	0V									
PIN 15	5V									
PIN 16	0V _ +4.7V						T=62usec			

RPS : REVERSE SEARCH
J-RPS : JET REVERSE SEARCH
J-FPS : JET FORWARD SEARCH


MODE PIN NO		IC902								
		STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL
PIN 1	0V									
PIN 2	0V _ +5V									
PIN 3	5V									
PIN 4	-2.5V _ +7.2V						T=1.5usec			
PIN 5	0V _ +5V						T=1.5usec			
PIN 6	0V									
PIN 7	0V _ +5V						T=40msec			
PIN 8	0V _ +5V									
PIN 9	0V _ +5V									
PIN 10	5V									
PIN 11	0V									
PIN 12	0V _ +3V									
PIN 13	0V _ +2.8V									
PIN 14	1V									
PIN 15	3V									
PIN 16	0.8V									
PIN 17	1.2V									
PIN 18	5V									
PIN 19	0V									
PIN 20	0V									
PIN 21	0V _ +5V						T=20msec			
PIN 22	0V _ +5V						T=20msec			
PIN 23	0V _ +5V						T=20msec			
PIN 24	0V _ +5V						T=20msec			
PIN 25	0V _ +5V						T=20msec			
PIN 26	0V _ +5V						T=20msec			
PIN 27	0V _ +5V						T=62usec			
PIN 28	2.2V + 3.2V						T=62usec			
PIN 29	1.6V _ +2.2V						T=0.06usec			
PIN 30	0V _ +5V									
PIN 31	0V _ +5V									
PIN 32	5V									

DECK JOINT

DECK JOINT

DECK JOINT

10-12. Deck Joint



RPS : REVERSE SEARCH

J-RPS : JET REVERSE SEARCH

J-FPS : JET FORWARD SEARCH


MODE PIN NO	IC 6201 TC4021BP									
	STOP	PLAY	REC	REW	FWD	RPS	J-RPS	J-FPS	STILL	
PIN 1	0	5	5	0	0	5	5	5	5	
PIN 2	0	0	0	5	5	5	5	0	0	
PIN 3	0	5	5	0	0	5	5	5	5	
PIN 4	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8	4.8	
PIN 5	5	4.8	4.8	4.8	5	4.8	4.8	4.8	4.8	
PIN 6	5	5	5	5	5	5	5	5	5	
PIN 7	0	0	0	2.6	2.6	2.2	2.2	2.2	0	
PIN 8	0	0	0	0	0	0	0	0	0	
PIN 9	5	5	5	5	5	5	5	5	5	
PIN 10	3	3	3	3.2	3.2	2	2	2	2	
PIN 11	0	0	0	0	0	0	0	0	0	
PIN 12	5	5	5	5	5	0	0	5	5	
PIN 13	5	0	0	0	0	5	0	0	5	
PIN 14	0	0	0	5	5	5	5	0	0	
PIN 15	5	5	5	5	5	0	0	5	5	
PIN 16	5	5	5	5	5	5	5	5	5	

SPECIAL NOTE
All integrated circuits and many other semiconductor devices are electrostatically sensitive and therefore require the special handling techniques described under the "electrostatically sensitive (ES) devices" section of this service manual.

NOTE
Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list. And may be slightly different or amended since this drawing was prepared.


FUNCTION

10-13. Function (VX/VI-1560)



FUNCTION

10-14. Function (VX-1561)




FUNCTION

REMOTE CONTROL

REMOTE CONTROL


10-16. Remote Control



SPEED SUB

SPEED SUB

10-15. Speed SUB (OPTION)



MINANCE/ ROMINANCE

LUMINANCE/ CHROMINANCE




















FIGURE	DESCRIPTION	LOCATION NO	FIGURE	DESCRIPTION	LOCATION NO
VIDEO BOARD			TUNER BOARD		
	LA 7323	IC 3201		LA 7545	IC 401
	MSM7401RS	IC 3202	AUDIO BOARD		
	LA 7331	IC 3401		LA 7295	IC 501
	BA 7025L	IC 3402		KSC 1008	Q 503 Q 504 Q 507
	TA 7348P	IC 3501	VPS BOARD (OPTION)		
	KSR 1002	Q 3201 Q 3202 Q 3216		SAA 4700	IC 6101
	A 643	Q 3203 Q 3217	OSD BOARD (OPTION)		
	KSR 2004	Q 2206		NJM 2229S	IC 901
	KSR 2001	Q 3215		M50554-001SP	IC 902
	KSR 1004	Q 3414 Q 3416		C 945	Q 901, Q 902 Q 903, Q 904
	KSC 1008	Q 3501		A 733	Q 906
				ASR 1001	Q 905 Q 907

FIGURE	DESCRIPTION	LOCATION NO
LP SKEW BOARD		
	AN 3592K	IC 01
	MST 001RS	IC 02
	MSM 6989RS	IC 03
	KA 8402 (TA 7347P)	IC 04
	C 945	Q A02 Q A04 Q A10
	KSR 1004	Q A03 Q A05 Q A15 Q A20
	A 733	Q A09 Q A11
	KSR 2001	Q A14

11. SEMICONDUCTOR LEAD IDENTIFICATION

FIGURE	DESCRIPTION	LOCATION NO	FIGURE	DESCRIPTION	LOCATION NO
DECK JOINT BOARD			SERVO BOARD		
	TC 4021BP	IC 6201		HD 49748NT	IC 201
	C 945	Q 6201		LM 393	IC 202
PRE-AMP BOARD				LM 358S	IC 203
	LA 7320	IC 3101		TC 4098BP	IC 204, IC 205
	A 733	Q 3101		KA 8301	IC 206
	C 945	Q 3102 Q 3103 Q 3104		KSR 1003 KSR 1004	Q 205, Q 213 Q 214
SYSTEM CONTROL/TIMER BOARD				A 733 C 945	Q 207, Q 210 Q 211 Q 209, Q 212
	UPD 759216 ACW-A75	IC 701		KSA 928A	Q 215
	KM 93C46	IC 702		KSD 261	Q 216
	MN 1280-Q	IC 703		KSR 2003	Q 217
	C 945	Q 701, Q 702			